

HEATER & AIR CONDITIONER

SECTION **HA**

CONTENTS

	AUTO	
PRECAUTIONS	3	
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	
Precautions for Working with HFC-134a (R-134a)	3	
General Refrigerant Precautions	4	
Precautions for Refrigerant Connection	4	
Precautions for Servicing Compressor	7	
Precautions for Service Equipment	7	
Wiring Diagrams and Trouble Diagnoses	9	
PREPARATION	10	
Special Service Tools	10	
HFC-134a (R-134a) Service Tools and Equipment	11	
DESCRIPTION	13	
Refrigeration System	13	
V-6 Variable Displacement Compressor	14	
Component Layout	19	
Introduction	20	
Features	20	
Overview of Control System	23	
Control Operation	23	
Discharge Air Flow	26	
System Description	27	
TROUBLE DIAGNOSES	29	
Component Location	29	
Circuit Diagram	31	
Wiring Diagram - A/C, A -	32	
Auto Amp. Terminals and Reference Value	36	
Self-diagnosis	38	
How to Perform Trouble Diagnoses for Quick and Accurate Repair	48	
Operational Check	49	
A/C System	53	
Mode Door Motor	56	
Air Mix Door Motor	62	
Intake Door Motor	65	
Blower Motor	68	

Magnet Clutch	76
Insufficient Cooling	82
Insufficient Heating	90
Noise	91
Self-diagnosis	92
Memory Function	93
ECON (ECONOMY) Mode	94
Ambient Sensor Circuit	94
In-vehicle Sensor Circuit	97
Sunload Sensor Circuit	101
Intake Sensor Circuit	104
Air Mix Door Motor PBR Circuit	107
SERVICE PROCEDURE	108
HFC-134a (R-134a) Service Procedure	108
Maintenance of Lubricant Quantity in Compressor	110
Compressor	113
Compressor Clutch	113
Heater Unit (Heater Core)	117
Blower and Cooling Unit (A/C Evaporator)	118
Refrigerant Lines	119
Belt	123
Idle Air Control Valve (IACV) - Auxiliary Air Control (AAC) Valve	124
Ventilation Air Filter	124
SERVICE DATA AND SPECIFICATIONS (SDS)	125
Auto	125

	MANUAL	
PRECAUTIONS	126	
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	126	
Precautions for Working with HFC-134a (R-134a)	126	
General Refrigerant Precautions	127	
Precautions for Refrigerant Connection	127	
Precautions for Servicing Compressor	130	
Precautions for Service Equipment	130	
Wiring Diagrams and Trouble Diagnoses	132	

CONTENTS (Cont'd)

PREPARATION	133	Intake Door	167
Special Service Tools	133	Blower Motor.....	170
HFC-134a (R-134a) Service Tools and Equipment.....	134	Magnet Clutch.....	176
DESCRIPTION	136	Insufficient Cooling	183
Refrigeration System	136	Insufficient Heating	191
V-6 Variable Displacement Compressor.....	137	Noise.....	192
Component Layout	142	SERVICE PROCEDURE	193
Control Operation	143	HFC-134a (R-134a) Service Procedure	193
Discharge Air Flow.....	144	Maintenance of Lubricant Quantity in Compressor	195
System Description.....	145	Compressor	198
TROUBLE DIAGNOSES	146	Compressor Clutch.....	198
Component Location.....	146	Heater Unit (Heater Core)	202
Circuit Diagram - Air Conditioner.....	148	Blower and Cooling Unit (A/C Evaporator)	203
Wiring Diagram - A/C, Heater -	149	Refrigerant Lines	204
Wiring Diagram - A/C, M -	150	Belt.....	208
How to Perform Trouble Diagnoses for Quick and Accurate Repair	154	Idle Air Control Valve (IACV) - Auxiliary Air Control (AAC) Valve	209
Operational Check	155	Ventilation Air Filter.....	209
A/C System.....	157	SERVICE DATA AND SPECIFICATIONS (SDS)	210
Mode Door.....	160	Manual	210
Air Mix Door.....	163		

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NFHA0270

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL A33 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

Precautions for Working with HFC-134a (R-134a)

NFHA0154

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. These refrigerants must never be mixed, even in the smallest amounts. If the refrigerants are mixed and compressor failure is likely to occur.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubricant other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - a) When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b) When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - c) Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - d) Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Use only approved recovery/recycling equipment to discharge HFC-134a (R-134a) refrigerant. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e) Do not allow lubricant (Nissan A/C System Oil Type S) to come in contact with styrofoam parts. Damage may result.

General Refrigerant Precautions

=NFHA0155

WARNING:

- Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.
- Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
- Do not store or heat refrigerant containers above 52°C (125°F).
- Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.
- Do not intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.
- Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Do not pressure test or leak test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and R-134a have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.

Precautions for Refrigerant Connection

NFHA0156


A new type refrigerant connection has been introduced to all refrigerant lines except the following location.

- Expansion valve to cooling unit

FEATURES OF NEW TYPE REFRIGERANT CONNECTION

NFHA0156S01

- The O-ring has been relocated. It has also been provided with a groove for proper installation. This eliminates the chance of the O-ring being caught in, or damaged by, the mating part. The sealing direction of the O-ring is now set vertically in relation to the contacting surface of the mating part to improve sealing characteristics.
- The reaction force of the O-ring will not occur in the direction that causes the joint to pull out, thereby facilitating piping connections.




PRECAUTIONS

AUTO*Precautions for Refrigerant Connection (Cont'd)*

O-RING AND REFRIGERANT CONNECTION

NFHA0156S02

This illustration is for LHD models.
The layout for RHD models is symmetrically opposite.



RHA452HA

CAUTION:

The new and former refrigerant connections use different O-ring configurations. Do not confuse O-rings since they are not interchangeable. If a wrong O-ring is installed, refrigerant will leak at, or around, the connection.


PRECAUTIONS

AUTO

Precautions for Refrigerant Connection (Cont'd)

O-Ring Part Numbers and Specifications

NFHA0156S0201

	Connection type	O-ring size	Part number	D mm (in)	W mm (in)
	New	8	92471 N8210	6.8 (0.268)	1.85 (0.0728)
	Former		92470 N8200	6.07 (0.2390)	1.78 (0.0701)
	New	12	92472 N8210	10.9 (0.429)	2.43 (0.0957)
	Former		92475 71L00	11.0 (0.433)	2.40 (0.0945)
	New	16	92473 N8210	13.6 (0.535)	2.43 (0.0957)
	Former		92475 72L00	14.3 (0.563)	2.30 (0.0906)
	New	19	92474 N8210	16.5 (0.650)	2.43 (0.0957)
	Former		92477 N8200	17.12 (0.6740)	1.78 (0.0701)

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.


CAUTION:

When replacing or cleaning refrigerant cycle components, observe the following.

- When the compressor is removed, store it in the same position as it is when mounted on the car. Failure to do so will cause lubricant to enter the low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, immediately plug all openings to prevent entry of dirt and moisture.
- When installing an air conditioner in the vehicle, connect the pipes as the final stage of the operation. Do not remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to circle of the O-rings shown in illustration. Be careful not to apply lubricant to threaded portion.
Lubricant name: Nissan A/C System Oil Type S
Part number: KLH00-PAGS0
- O-ring must be closely attached to dented portion of tube.
- When replacing the O-ring, be careful not to damage O-ring and tube.
- Connect tube until you hear it click, then tighten the nut or bolt by hand until snug. Make sure that the O-ring is installed to tube correctly.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.

AUTO

Precautions for Servicing Compressor



Precautions for Servicing Compressor

NFHA0157

- Plug all openings to prevent moisture and foreign matter from entering.
- When the compressor is removed, store it in the same position as it is when mounted on the car.
- When replacing or repairing compressor, follow “Maintenance of Lubricant Quantity in Compressor” exactly. Refer to HA-110.
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated, with lubricant, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour.
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation.

Precautions for Service Equipment

RECOVERY/RECYCLING EQUIPMENT

NFHA0158

RECOVERY/RECYCLING EQUIPMENT


NFHA0158S01

Be certain to follow the manufacturers instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

NFHA0158S02

Be certain to follow the manufacturer's instructions for tester operation and tester maintenance.



VACUUM PUMP


NFHA0158S03

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched off after evacuation (vacuuming) and hose is connected to it.

To prevent this migration, use a manual valve placed near the hose-to-pump connection, as follows.

- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut off valve, disconnect the hose from the pump. As long as the hose is connected, the valve is open and lubricating oil may migrate.


Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.



MANIFOLD GAUGE SET

NFHA0158S04


Be certain that the gauge face indicates R-134a or 134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.



SERVICE HOSES

NFHA0158S05

Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must include positive shut off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.




SERVICE COUPLERS

NFHA0158S06

Never attempt to connect HFC-134a (R-134a) service couplers to an CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

PRECAUTIONS

AUTO*Precautions for Service Equipment (Cont'd)*

REFRIGERANT WEIGHT SCALE

NFHA0158S07

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. If the scale controls refrigerant flow electronically, the hose fitting must be 1/2"-16 ACME.

CALIBRATING ACR4 WEIGHT SCALE

NFHA0158S08

Calibrate the scale every three months.

To calibrate the weight scale on the ACR4:

1. Press **Shift/Reset** and **Enter** at the same time.
2. Press **8787**. "A1" will be displayed.
3. Remove all weight from the scale.
4. Press **0**, then press **Enter**. "0.00" will be displayed and change to "A2".
5. Place a known weight (dumbbell or similar weight), between 4.5 and 8.6 kg (10 and 19 lb) on the center of the weight scale.
6. Enter the known weight using four digits. (Example 10 lb = 10.00, 10.5 lb = 10.50)
7. Press **Enter** — the display returns to the vacuum mode.
8. Press **Shift/Reset** and **Enter** at the same time.
9. Press **6** — the known weight on the scale is displayed.
10. Remove the known weight from the scale. "0.00" will be displayed.
11. Press **Shift/Reset** to return the ACR4 to the program mode.

CHARGING CYLINDER

NFHA0158S09

Using a charging cylinder is not recommended. Refrigerant may be vented into air from cylinder's top valve when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

Wiring Diagrams and Trouble Diagnoses

NFHA0159

When you read wiring diagrams, refer to the following:






- **GI-11**, "HOW TO READ WIRING DIAGRAMS" in GI section
- **EL-9**, "Wiring Diagram — POWER —" for power distribution circuit in EL section

When you perform trouble diagnoses, refer to the following:

- **GI-33**, "HOW TO FOLLOW TROUBLE DIAGNOSES" in GI section
- **GI-22**, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section

Special Service Tools

NFHA0160

Tool number Tool name	Description
KV99106100 Clutch disc wrench	<p>Removing center bolt</p>  <p>NT232</p>  <p>When replacing the magnet clutch in the above compressor, use a clutch disc wrench with the pin side on the clutch disc to remove it.</p>  <p>NT378</p>
KV99232340 or KV992T0001 Clutch disc puller	<p>Removing clutch disc</p>  <p>NT376</p>
KV99106200 Pulley installer	<p>Installing pulley</p>  <p>NT235</p>

PREPARATION

AUTO

HFC-134a (R-134a) Service Tools and Equipment

HFC-134a (R-134a) Service Tools and Equipment






=NFHA0161

Never mix HFC-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.

Separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubricant.

Refrigerant container fittings, service hose fittings and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and HFC-134a (R-134a). This is to avoid mixed use of the refrigerants/lubricant.





Adapters that convert one size fitting to another must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.

Tool number Tool name	Description
HFC-134a (R-134a) refrigerant	 <p>Container color: Light blue Container marking: HFC-134a (R-134a) Fitting size: Thread size</p> <ul style="list-style-type: none"> • Large container 1/2"-16 ACME <p>NT196</p>
KLH00-PAGS0 Nissan A/C System Oil Type S	 <p>Type: Poly alkylene glycol oil (PAG), type S Application: HFC-134a (R-134a) swash plate (piston) compressors (Nissan only) Lubricity: 40 ml (1.4 Imp fl oz)</p> <p>NT197</p>
Recovery/Recycling Recharging equipment (ACR4)	 <p>Function: Refrigerant Recovery and Recycling and Recharging</p> <p>NT195</p>
Electrical leak detector	 <p>Power supply:</p> <ul style="list-style-type: none"> • DC 12V (Cigarette lighter) <p>NT198</p>
Manifold gauge set (with hoses and couplers)	 <p>Identification:</p> <ul style="list-style-type: none"> • The gauge face indicates R-134a. <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> • 1/2"-16 ACME <p>NT199</p>

PREPARATION

AUTO

HFC-134a (R-134a) Service Tools and Equipment (Cont'd)

Tool number Tool name	Description
Service hoses <ul style="list-style-type: none"> • High side hose • Low side hose • Utility hose 	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Hose color:</p> <ul style="list-style-type: none"> • Low hose: Blue with black stripe • High hose: Red with black stripe • Utility hose: Yellow with black stripe or green with black stripe <p>Hose fitting to gauge:</p> <ul style="list-style-type: none"> • 1/2"-16 ACME </div> </div> <p style="text-align: center;">NT201</p>
Service couplers <ul style="list-style-type: none"> • High side coupler • Low side coupler 	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Hose fitting to service hose:</p> <ul style="list-style-type: none"> • M14 x 1.5 fitting is optional or permanently attached. </div> </div> <p style="text-align: center;">NT202</p>
Refrigerant weight scale	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>For measuring of refrigerant</p> <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> • 1/2"-16 ACME </div> </div> <p style="text-align: center;">NT200</p>
Vacuum pump (Including the isolator valve)	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Capacity:</p> <ul style="list-style-type: none"> • Air displacement: 4 CFM • Micron rating: 20 microns • Oil capacity: 482 g (17 oz) <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> • 1/2"-16 ACME </div> </div> <p style="text-align: center;">NT203</p>

Refrigeration System

REFRIGERATION CYCLE

Refrigerant Flow

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the liquid tank, through the evaporator, and back to the compressor. The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case. NFHA0162S01

Freeze Protection

Under normal operating conditions, when the A/C is switched on, the compressor runs continuously, and the evaporator pressure, and therefore, temperature is controlled by the V-6 variable displacement compressor to prevent freeze up. NFHA0162S02


Refrigerant System Protection

Refrigerant Pressure Sensor

The refrigerant system is protected against excessively high or low pressures by the refrigerant pressure sensor, located on the liquid tank. If the system pressure rises above, or falls below the specifications, the refrigerant pressure sensor detects the pressure inside the refrigerant line and sends the voltage signal to the ECM. ECM makes the A/C relay go OFF and stops the compressor when pressure on the high pressure side detected by refrigerant pressure sensor is over about 2,746 kPa (27.5 bar, 28 kg/cm², 398 psi), or below about 177 kPa (1.77 bar, 1.8 kg/cm², 26 psi). NFHA0162S03

Pressure Relief Valve

The refrigerant system is also protected by a pressure relief valve, located in the rear head of the compressor. When the pressure of refrigerant in the system increases to an abnormal level [more than 3,727 kPa (37.3 bar, 38 kg/cm², 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere. NFHA0162S0302



V-6 Variable Displacement Compressor**GENERAL INFORMATION**

=NFHA0163

1. The V-6 variable compressor differs from previous units. The vent temperatures of the V-6 variable compressor do not drop too far below 5°C (41°F) when:
 - evaporator intake air temperature is less than 20°C (68°F)
 - engine is running at speeds less than 1,500 rpm.This is because the V-6 compressor provides a means of “capacity” control.
2. The V-6 variable compressor provides refrigerant control under varying conditions. During cold winters, it may not produce high refrigerant pressure discharge (compared to previous units) when used with air conditioning systems.
3. A “clanking” sound may occasionally be heard during refrigerant charge. The sound indicates that the tilt angle of the swash plate has changed and is not a problem.
4. For air conditioning systems with the V-6 compressor, the clutch remains engaged unless: the system main switch, fan switch or ignition switch is turned OFF. When ambient (outside) temperatures are low or when the amount of refrigerant is insufficient, the clutch is disengaged to protect the compressor.
5. A constant range of suction pressure is maintained when engine speed is greater than a certain value. It normally ranges from 147 to 177 kPa (1.47 to 1.77 bar, 1.5 to 1.8 kg/cm², 21 to 26 psi) under varying conditions.

In previous compressors, however, suction pressure was reduced with increases in engine speed.

DESCRIPTION

AUTO

V-6 Variable Displacement Compressor (Cont'd)

DESCRIPTION



General

=NFHA0164

NFHA0164S01

The variable compressor is basically a swash plate type that changes piston stroke in response to the required cooling capacity.

The tilt of the swash plate allows the piston's stroke to change so that refrigerant discharge can be continuously changed from 14.5 to 184 cm³ (0.885 to 11.228 cu in).



Discharge control	Discharge capacity cm ³ (cu in)/rev.	Piston stroke length mm (in)
Minimum	14.5 (0.885)	2.3 (0.091)
Maximum	184 (11.228)	28.6 (1.126)

RHA037DD

Operation

1. Operation Control Valve

=NFHA0164S02

NFHA0164S0201

Operation control valve is located in the suction port (low-pressure) side, and opens or closes in response to changes in refrigerant suction pressure.

Operation of the valve controls the internal pressure of the crankcase.

The angle of the swash plate is controlled between the crankcase's internal pressure and the piston cylinder pressure.

2. Maximum Cooling

NFHA0164S0202


Refrigerant pressure on the low-pressure side increases with an increase in heat loads.

When this occurs, the control valve's bellows compress to open the low-pressure side valve and close the high-pressure side valve.

This causes the following pressure changes:

- the crankcase's internal pressure to equal the pressure on the low-pressure side;
- the cylinder's internal pressure to be greater than the crankcase's internal pressure.


Under this condition, the swash plate is set to the maximum stroke position.



3. Capacity Control

=NFHA0164S0203

- Refrigerant pressure on suction side is low during high speed driving or when ambient or interior temperature is low.
 - The bellows expands when refrigerant pressure on the suction pressure side drops below approximately 177 kPa (1.77 bar, 1.8 kg/cm², 26 psi). Since suction pressure is low, it makes the suction port close and the discharge port open. Thus, crankcase pressure becomes high as high pressure enters the crankcase.
 - The force acts around the journal pin near the swash plate, and is generated by the pressure difference before and behind the piston.
- The drive lug and journal pin are located where the piston generates the highest pressure. Piston pressure is between suction pressure P_s and discharge pressure P_d , which is near suction pressure P_s . If crankcase pressure P_c rises due to capacity control, the force around the journal pin makes the swash plate angle decrease and also the piston stroke decrease. In other words, crankcase pressure increase triggers pressure difference between the piston and the crankcase. The pressure difference changes the angle of the swash plate.



RHA474C

IACV-AAC CONTROL SYSTEM

=NFHA0165

Operation


NFHA0165S02

When the air conditioner is OFF, the ECM detects the load applied to the engine, and controls the IACV-AAC valve to adjust the engine idling speed to the appropriate rpm by supplying additional air from the IACV-AAC valve.

When the air conditioner is ON (A/C relay is ON), refrigerant-pressure sensor converts refrigeration-pressure on the high pressure side into the voltage value, which is output to ECM which protects refrigeration cycle and control idle speed by the output voltage data, and additional air is supplied to the engine. If the appropriate engine speed is not reached, the IACV-AAC valve supplies the additional air required to increase the engine rpm.

Component Layout

NFHA0166



RHA349HA


Introduction

AIR CONDITIONER LAN SYSTEM OVERVIEW CONTROL SYSTEM

NFHA0167

NFHA0167S01

The LAN system consists of auto amp., mode door motor, air mix door motor and intake door motor. A configuration of these components is shown in the diagram below.



RHA439GB

Features

NFHA0168

SYSTEM CONSTRUCTION (LAN)


NFHA0168S01

A small network is constructed between the auto amplifier, mode door motor, air mix door motor and intake door motor. The auto amplifier and motors are connected by data transmission lines and motor power supply lines. The LAN network is built through the ground circuits of the three motors.

Addresses, motor opening angle signals, motor stop signals and error checking messages are all transmitted through the data transmission lines connecting the auto amplifier and three motors.

The following functions are contained in LCUs built into the mode door motor, air mix door motor and the intake door motor.

- Address
- Motor opening angle signals
- Data transmission
- Motor stop and drive decision
- Opening angle sensor (PBR function)
- Comparison
- Decision (Auto amplifier indicated value and motor opening angle comparison)




RHA350H

Operation

NFHA0168S0101

The auto amplifier receives data from each of the sensors. The amplifier sends mode door, air mix door and intake door opening angle data to the mode door motor LCU, air mix door LCU and intake door motor LCU. The mode door motor, air mix door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/COLD, FRESH/RECIRCULATION or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier.



Transmission Data and Transmission Order

NFHA0168S0102

Amplifier data is transmitted consecutively to each of the door motors following the form shown in figure below. Start: Initial compulsory signal sent to each of the door motors.

Address: Data sent from the auto amplifier is selected according to data-based decisions made by the mode door motor, air mix door motor and intake door motor.

If the addresses are identical, the opening angle data and error check signals are received by the door motor LCUs. The LCUs then make the appropriate error decision. If the opening angle data is normal, door control begins.


If an error exists, the received data is rejected and corrected data received. Finally, door control is based upon the corrected opening angle data.

Opening angle: Data that shows the indicated door opening angle of each door motor.

Error check: Procedure by which sent and received data is checked for errors. Error data is then compiled. The error check prevents corrupted data from being used by the mode door motor, air mix door motor and intake door motor. Error data can be related to the following problems.

- Abnormal electrical frequency
- Poor electrical connections
- Signal leakage from transmission lines
- Signal level fluctuation

Stop signal: At the end of each transmission, a stop operation, in-operation, or internal problem message is delivered to the auto amplifier. This completes one data transmission and control cycle.



Air Mix Door Control (Automatic Temperature Control)

NFHA0168S0103

The air mix door is automatically controlled so that in-vehicle temperature is maintained at a predetermined value by: The temperature setting, ambient temperature, in-vehicle temperature and amount of sunload.

Features (Cont'd)

Fan Speed Control

NFHA0168S0104

Blower speed is automatically controlled based on temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.

With FAN switch set to "AUTO", the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

Intake Door Control

NFHA0168S0105

The intake doors are automatically controlled based on temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload, air mix door position and ON-OFF operation of the compressor.

Outlet Door Control

NFHA0168S0106

The outlet door is automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

Magnet Clutch Control

NFHA0168S0107

The ECM controls compressor operation using input signals from the throttle position sensor, refrigerant pressure sensor and auto amplifier.

Self-diagnostic System


NFHA0168S0108

The self-diagnostic system is built into the auto amplifier (LCU) to quickly locate the cause of problems.

Overview of Control System

=NFHA0169

The control system consists of input sensors, switches, the automatic amplifier (microcomputer) and outputs. The relationship of these components is shown in the diagram below:




RHA550HA


Control Operation

NFHA0170

LHD models



RHA354HC



DISPLAY SCREEN

Displays the operational status of the system.

NFHA0170S01

AUTO SWITCH

The compressor, intake doors, air mix door, outlet doors, and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.

NFHA0170S02

RHD models:

Pressing the AUTO switch illuminates the A/C switch indicator (RHD) when the A/C switch is ON before the AUTO switch is pressed, and turns ON the compressor.

ECON SWITCH (LHD MODELS)

By pressing the ECON switch, the display should indicate ECON and the compressor always turns OFF. With the compressor OFF, the system will not remove heat (cool) or de-humidify. The system will maintain the in-vehicle temperature at the set temperature when the set temperature is above the ambient (outside) temperature. The system will set the intake doors to the outside air position.

NFHA0170S03

TEMPERATURE DIAL (POTENTIO TEMPERATURE CONTROL)

Increases or decreases the set temperature.

NFHA0170S04

OFF SWITCH





The compressor and blower are OFF, the intake doors are set to the outside air position, and the air outlet doors are set to the foot (80% foot and 20% defrost) position.

NFHA0170S05

FAN SWITCH

Manual control of the blower speed. Four speeds are available for manual control (as shown on the display screen):

NFHA0170S06

low , medium low , medium high , high 

FRESH SWITCH (RHD MODELS)

OFF position: Interior air is recirculated inside the vehicle.

NFHA0170S11

ON position: Outside air is drawn into the passenger compartment.

(When RECIRCULATION switch is ON, the FRESH switch turns OFF automatically.)

A/C SWITCH (RHD MODELS)

The compressor is ON or OFF.

NFHA0170S12

(Pressing the A/C switch when the AUTO switch is ON will turn off the A/C switch and compressor.)

RECIRCULATION (REC) SWITCH

NFHA0170S07

OFF position: Outside air is drawn into the passenger compartment.

ON position: Interior air is recirculated inside the vehicle.

(When the FRESH switch is ON (RHD models) or the compressor is turned from ON to OFF, the RECIRCULATION switch turns OFF) automatically.

DEFROSTER (DEF) SWITCH

NFHA0170S08

Positions the air outlet doors to the defrost position. Also positions the intake doors to the outside air position.

MODE SWITCHES

NFHA0170S09

Control the air discharge outlets.

REAR WINDOW DEFOGGER SWITCH

NFHA0170S10

When illumination is ON, rear window is defogged.


AMBIENT SWITCH

NFHA0170S13


Shows the ambient (outside) air temperature on display screen for 5 seconds.

Discharge Air Flow



NFHA0171




Face
(switch "ON")




Bi-level
(switch "OFF")



Floor and defroster



Defroster



This illustration is for LHD models.
The layout for RHD models is symmetrically opposite.


RHA355HA

System Description

NFHA0246

SWITCHES AND THEIR CONTROL FUNCTIONS











NFHA0246S01



SHA378F

LHD models

NFHA0246S0101

Position or switch	MODE SW				Front DEF SW		ECON SW	AUTO SW	REC SW		Temperature DIAL			OFF SW
	VENT	B/L	FOOT	D/F	ON	OFF			ON	OFF	<div>TEMP</div>			
							ECON	AUTO						
Door											18.0°C (65°F)	—	32.0°C (85°F)	
Ventila- tor door	A	B	C	C	C	—	AUTO	AUTO	—		—			C
Foot door	C	B	A	B	C				—		—			A
Defroster door	D	D	C	B	A				—		—			C
Air mix door	—				—				—		B	AUTO	A	—
Intake door	—				A				B	AUTO*1	—			—

*1: Automatically controlled when REC switch is OFF.














DESCRIPTION

AUTO

System Description (Cont'd)

RHD models

NFHA0246S0102

Position or switch	MODE SW				Front DEF SW		A/C SW	AUTO SW	Intake SW		Temperature DIAL			OFF SW	
	VENT	B/L	FOOT	D/F	ON	OFF			REC SW	FRE SW				OFF	
															
Door								AUTO				18.0°C (65°F)	—	32.0°C (85°F)	
Ventilator door	A	B	C	C	C	—	—	AUTO				—			C
Foot door	C	B	A	B	C							—			A
Defroster door	D	D	C	B	A							—			C
Air mix door	—				—							B	AUTO	A	—
Intake door	—				A			—	B	AUTO*1	A	—			—





*1: Automatically controlled when REC switch is OFF.

SHA379F

**Component Location
ENGINE COMPARTMENT**

NFHA0172



NFHA0172S01



RHA453H

PASSENGER COMPARTMENT


NFHA0172S02



This illustration is for LHD models.
The layout for RHD models is symmetrically opposite.

RHA454HA

Circuit Diagram



Wiring Diagram — A/C, A —

Wiring Diagram — A/C, A —


NFHA0174

HA-A/C,A-01

— : DATA LINE

L : LHD MODELS

R : RHD MODELS



1	(M49), (M51), (M84)
2	W
3	W

10	9	8	7	6	5	4	3	2	1	(M59)
20	19	18	17	16	15	14	13	12	11	GY

28	27	26	25	24	23	22	21	(M60)
36	35	34	33	32	31	30	29	GY

REFER TO THE FOLLOWING.
 (M17), (M19) - FUSE BLOCK -
 JUNCTION BOX (J/B)



MHA995A

LHD MODELS

=NFHA0174S01

HA-A/C,A-02

BC :WITH BOARD
COMPUTER



REFER TO THE FOLLOWING.
(M15) - SUPER
 MULTIPLE JUNCTION (SMJ)
(F48) - ELECTRICAL UNITS




MHA971A

RHD MODELS

=NFHA0174S02

HA-A/C,A-03

⬢BC : WITH BOARD COMPUTER





REFER TO THE FOLLOWING.
 (M15) - SUPER
 MULTIPLE JUNCTION (SMJ)
 (F48) - ELECTRICAL UNITS


MHA972A

AUTO

HA-A/C,A-04



HA-35



Auto Amp. Terminals and Reference Value



INSPECTION OF AUTO AMP.

NFHA0175

NFHA0175S01

- Measure voltage between each terminal and body ground by following "AUTO AMP. INSPECTION TABLE".

- Pin connector terminal layout



RHA501GC

AUTO AMP. INSPECTION TABLE


NFHA0175S02

TERMINAL NO.	ITEM	CONDITION		Voltage V
1	Intake sensor	—		—
2	Ambient sensor	—		—
3	In-vehicle sensor	—		—
8	ECM COMP		Compressor ON	Approximately 0
			Compressor OFF	Approximately 4.6
11	Sensor ground		—	Approximately 0
12	Sunload sensor	—		—
13	Thermal transmitter		Engine coolant temperature	Approximately 40°C (104°F) Approximately 55°C (131°F) Approximately 60°C (140°F)
14	Ground		—	Approximately 0
16	A/C LAN signal		—	Approximately 5.5
21	Power supply for mode door motor, intake door motor and air mix door motor	—		Approximately 12
22	Compressor ON signal		Compressor	ON OFF
			—	Approximately 0 Approximately 4.6
26	Power supply for BAT		—	BATTERY VOLTAGE

TROUBLE DIAGNOSES

AUTO

Auto Amp. Terminals and Reference Value (Cont'd)

TERMINAL NO.	ITEM	CONDITION			Voltage V
27	Power supply for IGN		—		Approximately 12
28	Ambient temperature signal (With board computer)		—		Approximately 4.5
30	Rear window defogger feed back		Rear window defogger switch	ON	Approximately 12
				OFF	Approximately 0
31	Rear window defogger ON signal		Rear window defogger switch	ON	Approximately 0
				OFF	Approximately 12
32	Ground		—		Approximately 0
33	Power source for A/C		Ignition voltage feed back		Approximately 12
34	Blower motor feed back		Fan speed: Low		Approximately 7 - 10
35	Fan control AMP. control signal	Fan speed	Low, Middle low or Middle high	Approximately 2.5 - 3.0	
			High	Approximately 9 - 10	

Self-diagnosis


=NFHA0176

INTRODUCTION AND GENERAL DESCRIPTION

NFHA0176S01

The self-diagnostic system diagnoses sensors, door motors, blower motor, etc. by system line. Refer to applicable sections (items) for details. Shifting from normal control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from "OFF" to "ON") and pressing "OFF" switch for at least 5 seconds. The "OFF" switch must be pressed within 10 seconds after starting the engine (ignition switch is turned "ON"). This system will be canceled by either pressing **AUTO** (AUTO) switch or turning the ignition switch "OFF". Shifting from one step to another is accomplished by means of pushing TEMP dial right turn or TEMP dial left turn switch, as required.

Additionally shifting from STEP 5 to AUXILIARY MECHANISM is accomplished by means of pushing  (fan) UP switch.



Note:

For STEP 4 and 5, engine must be running for compressor to operate.

RHA357H

Perform all of the following tests to narrow the problem to a specific assembly, actuator, or function. Link to the Diagnostic Procedure which corresponds to malfunctions noted in these tests. If the A/C display screen has no display, check all power supply circuits to the A/C Auto Amp.

TROUBLE DIAGNOSES


AUTO

Self-diagnosis (Cont'd)

FUNCTION CONFIRMATION PROCEDURE

NFHA0176S02

1	ENTER SELF-DIAGNOSTIC MODE
<p>Perform steps 1 - 3</p> <ol style="list-style-type: none"> 1. Turn the ignition OFF. 2. Start the engine. 3. Immediately after starting the engine press and hold the OFF switch (for the auto A/C system) for at least 5 seconds. The A/C Auto Amp. should now be in Self Diagnosis mode. Self Diagnosis steps 1 - 5 can now be performed. Self Diagnosis step 1 will be displayed first. Shifting from one step to another is accomplished by pressing the temperature increase or decrease switch. 	
▶	GO TO 2.

2	STEP 1 LED/DISPLAY CHECK
<p>Verify all segments illuminate. If all segments do not illuminate the fluorescent display tube is malfunctioning or the system has not entered self diagnosis which would indicate a malfunctioning OFF switch. Do all LEDs and segments illuminate?</p>	
<p>Display malfunction</p> 	
RHA358H	
Yes or No	
Yes	▶ GO TO 3.
No	▶ Malfunctioning OFF switch, LED or fluorescent display tube. Replace A/C auto amp.


3	CHECK TO ADVANCE SELF-DIAGNOSIS STEP 2
<ol style="list-style-type: none"> 1. Turn the TEMP dial clockwise. 2. Advance to self-diagnosis STEP 2. <p>If the system does not shift between step 1 and 2 a malfunctioning TEMP dial is indicated.</p>	
Yes or No	
Yes	▶ GO TO 4.
No	▶ Malfunctioning TEMP dial. Replace A/C auto amp.


TROUBLE DIAGNOSES

AUTO

Self-diagnosis (Cont'd)

4	CHECK TO RETURN SELF-DIAGNOSIS STEP 1
1. Turn the TEMP dial counterclockwise. 2. Return to self-diagnosis STEP 1. If the system does not shift between step 1 and 2 a malfunctioning TEMP dial is indicated.	
Yes or No	
Yes	▶ GO TO 5.
No	▶ Malfunctioning TEMP dial. Replace A/C auto amp.


5	STEP 2 - SENSOR CIRCUITS ARE CHECKED FOR OPEN OR SHORT CIRCUIT
Turn the TEMP dial clockwise, advance to STEP 2: Wait (about 25 seconds) for two digit Code to appear. This is the Electronic Sensor Input Check which includes circuits. Does code No. 20 appear on the display?	
<p>Display (when all sensors are in good order)</p> <p>Illuminates 25 seconds after "2" is illuminated.</p> <p>Illuminates</p> 	
RHA970DB	
Yes or No	
Yes	▶ GO TO 6.
No	▶ GO TO 13.

6	STEP 3 - MODE DOOR AND INTAKE DOOR POSITIONS ARE CHECKED
Turn the TEMP dial clockwise, advance to STEP 3. Wait (about 50 seconds) for two digit Code to appear. This is the Mode Door and Intake Door Position Switch input checks including circuits. Does code No. 30 appear on the display?	
<p>Display (when all doors are in good order)</p> <p>Illuminates 50 seconds after "3" is shown on display.</p> <p>Illuminates</p> 	
RHA869DD	
Yes or No	
Yes	▶ GO TO 7.
No	▶ GO TO 14.

TROUBLE DIAGNOSES

AUTO

Self-diagnosis (Cont'd)

7	STEP 4 - OPERATION OF EACH ACTUATOR IS CHECKED
<p>Turn the TEMP dial clockwise, advance to STEP 4. Engine running. This is Heater and A/C system check. Code 41 will be displayed. Use the DEF switch to advance the code number from 41 to 46. After 46, the display will return to code 41 and can be advanced to 46 again.</p> <div> <div>Changes from "1" to "5".</div> <div> <div>Illuminates</div>  </div> </div>	
<div>▶</div> <div>GO TO 8.</div>	

RHA495A

TROUBLE DIAGNOSES

AUTO

Self-diagnosis (Cont'd)

8

CHECK ACTUATORS

Confirm operation of system components according to the following charts.

Checks must be made visually, by listening to any noise, or by touching air outlets with your hand, etc. for improper operation.

Code No.	41	42	43	44	45	46
Actuator						
Mode door	VENT	B/L	B/L	FOOT	D/F	DEF
Intake door	REC	REC	20% FRE	FRE	FRE	FRE
Air mix door	Full Cold	Full Cold	Full Hot	Full Hot	Full Hot	Full Hot
Blower motor	4.5 V	10.5 V	8.5 V	8.5 V	8.5 V	12 V
Compressor	ON	ON	OFF	OFF	ON	ON

Operating condition of each actuator cannot be checked by indicators.

Discharge air flow

Mode switch	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	80%	20%
	—	60%	40%
	—	—	100%

OK or NG

OK	▶	GO TO 9.
NG	▶	<ul style="list-style-type: none"> Air outlet does not change. Go to “Mode Door Motor” (HA-56). Intake door does not change. Go to “Intake Door Motor” (HA-65). Blower motor operation is malfunctioning. Go to “Blower Motor” (HA-68). Magnet clutch does not engage. Go to “Magnet Clutch” (HA-76). Discharge air temperature does not change. Go to “Air Mix Door Motor” (HA-62).


MTBL0394


MTBL0128


TROUBLE DIAGNOSES

AUTO




Self-diagnosis (Cont'd)

9	STEP 5 - TEMPERATURE OF EACH SENSOR IS CHECKED
<p>Turn the TEMP dial clockwise, advance to STEP 5. This is Intake sensor, In Vehicle sensor and Ambient Sensor function check. Code 51 will be displayed.</p> <p>NOTE: Each sensor reading should be approximately the actual temperature.</p> <p>"51" appears on display.</p>  <p style="text-align: right;">RHA359H</p>	
	<p>▶ GO TO 10.</p>

10	CHECK AMBIENT SENSOR
<p>Press DEF once, temperature detected by the Ambient Sensor is displayed.</p> <p>Temperature detected by ambient sensor.</p>  <p>Indicates negative temperature reading.</p> <p style="text-align: right;">RHA551H</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 11.
NG	▶ Go to Ambient Sensor Circuit (HA-94).

11	CHECK IN-VEHICLE SENSOR
<p>Press DEF second time, temperature detected by the In Vehicle Sensor is displayed.</p> <p>Temperature detected by in-vehicle sensor.</p>  <p>Indicates negative temperature reading.</p> <p style="text-align: right;">RHA552H</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 12.
NG	▶ Go to In-vehicle Sensor Circuit (HA-97).

Self-diagnosis (Cont'd)

12	CHECK INTAKE SENSOR	
Press DEF third time, temperature detected by the Intake Sensor is displayed.		
<div><p>Temperature detected by in-vehicle sensor.</p><p>Indicates negative temperature reading.</p><p>RHA553H</p></div>		
OK or NG		
OK	▶	1. Press  (DEF) switch the fourth time. Display returns to original presentation 51. 2. Turn ignition switch OFF or  (AUTO) switch ON. 3. END
NG	▶	Go to Intake Sensor Circuit (HA-104).

TROUBLE DIAGNOSES

AUTO

Self-diagnosis (Cont'd)

13 CHECK MALFUNCTIONING SENSOR

NOTE:

- A blinking mark (-) preceding the Code No. indicates a short circuit.
- If 2 or more items are malfunctioning the corresponding codes will alternately blink twice.
- A circuit will be detected as open or shorted and its code No. will be displayed when input signals correspond with conditions in the following chart.

Code No.	Sensor	Open circuit	Short circuit	Reference page
21	Ambient sensor	Less than -43.8°C (-47°F)	Greater than 100°C (212°F)	*3
-21				
22	In-vehicle sensor	Less than -43.8°C (-47°F)	Greater than 100°C (212°F)	*4
-22				
24	Intake sensor	Less than -43.8°C (-47°F)	Greater than 100°C (212°F)	*5
-24				
25	Sunload sensor*2	Less than 0.228 mA	Greater than 0.98 mA	*6
-25				
26	PBR*1	Greater than 95%	Less than 5%	*7
-26				

MTBL0401


*1: "95%" and "5%" refer to percentage with respect to stroke of air mix door. (Full cold: 0%, Full hot: 100%)

*2: **Conduct self-diagnosis STEP 2 under sunshine.**

When conducting indoors, direct light (more than 60W) at sunload sensor.

*3: HA-94, *4: HA-97, *5: HA-104, *6: HA-101, *7: HA-107

Display (when sensor malfunctions)



RHA455G

RHA501A



INSPECTION END

14	CHECK MALFUNCTIONING DOOR MOTOR POSITION SWITCH
<p>30- Mode door and intake door position switches are in working order. Continue to next step.</p> <p>31- Mode door circuit / switch in vent position switch is malfunctioning.</p> <p>32- Mode door circuit / switch in B/L position switch is malfunctioning.</p> <p>34- Mode door circuit / switch in Foot position switch is malfunctioning.</p> <p>35- Mode door circuit / switch in Foot Def. position switch is malfunctioning.</p> <p>36- Mode door circuit / switch in Def. position switch is malfunctioning.</p> <p>37- Intake door mode circuit / switch in Fresh Air position is malfunctioning.</p> <p>38- Intake door mode circuit / switch in 20% Fresh Air position is malfunctioning.</p> <p>39- Intake door mode circuit / switch in Recirculation Air position is malfunctioning.</p> <p>NOTE:</p> <ul style="list-style-type: none"> ● If 2 or more items are malfunctioning the corresponding codes will alternately blink twice. ● If the Mode Door Motor harness is disconnected repeated display pattern of 31 → 32 → 34 → 35 → 36 will occur. ● If Intake Door Motor harness is disconnected repeated display pattern of 37 → 38 → 39 will occur. ● If any Mode Door Motor Position Switch is malfunctioning the Mode Door Motor will also malfunction. <div> <div> Display (when a door is out of order) </div> <div> <div> Illuminates </div> <div> Code No. (blinks) </div> <div> </div> <div> <div> Each code No. blinks two times. </div> <div> </div> </div> <div> RHA168DA </div> <div> RHA498A </div> </div></div>	
▶	INSPECTION END


AUXILIARY MECHANISM: TEMPERATURE SETTING TRIMMER

=NFHA0176S03


Unconfirmed Incidents

NFHA0176S0301

The customer may feel that the cabin temperature is not being controlled or regulated to the temperature indicated by the auto A/C display screen. To satisfy individual driver preference the Temperature Setting Trimmer may be used to compensate in a range of $\pm 3^{\circ}\text{C}$ ($\pm 6^{\circ}\text{F}$).

1. Enter Self Diagnosis mode and select STEP 5.
2. Press the Fan Up  switch: This will set the A/C system in auxiliary mode and the display will show 61.
3. Turn the temperature dial clockwise or counterclockwise: The temperature will change at a rate of 0.5°C (1°F).

If power is lost to the A/C Auto Amp., trimmer setting is canceled and setting becomes that of initial condition, 0° .



RHA554H


When battery cable is disconnected, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e. 0°C (0°F).

How to Perform Trouble Diagnoses for Quick and Accurate Repair

=NFHA0177

NFHA0177S01

WORK FLOW



SHA900E

*1: Operational Check (HA-49)

SYMPTOM TABLE

NFHA0177S02

Symptom	Reference Page	
● A/C system does not come on.	● Go to Trouble Diagnosis Procedure for A/C system.	HA-53
● Air outlet does not change.	● Go to Trouble Diagnosis Procedure for Mode Door Motor. (LAN)	HA-56
● Mode door motor does not operate normally.		
● Discharge air temperature does not change.	● Go to Trouble Diagnosis Procedure for Air Mix Door Motor. (LAN)	HA-62
● Air mix door motor does not operate normally.		
● Intake door does not change.	● Go to Trouble Diagnosis Procedure for Intake Door Motor. (LAN)	HA-65
● Intake door motor does not operate normally.		
● Blower motor operation is malfunctioning.	● Go to Trouble Diagnosis Procedure for Blower Motor.	HA-68
● Blower motor operation is malfunctioning under out of starting fan speed control.		
● Magnet clutch does not engage.	● Go to Trouble Diagnosis Procedure for Magnet Clutch.	HA-76
● Insufficient cooling.	● Go to Trouble Diagnosis Procedure for Insufficient Cooling.	HA-82
● Insufficient heating.	● Go to Trouble Diagnosis Procedure for Insufficient Heating.	HA-90
● Noise.	● Go to Trouble Diagnosis Procedure for Noise.	HA-91
● Self-diagnosis can not be performed.	● Go to Trouble Diagnosis Procedure for Self-diagnosis.	HA-92
● Memory function does not operate.	● Go to Trouble Diagnosis Procedure for Memory Function.	HA-93
● ECON mode does not operate.	● Go to Trouble Diagnosis Procedure for ECON (ECONOMY) — mode.	HA-94

Operational Check


The purpose of the operational check is to confirm that the system operates properly.

NFHA0178

CONDITIONS:

- Engine running and at normal operating temperature.

NFHA0178S01



SHA397F

PROCEDURE:

1. Check Memory Function


NFHA0178S02

NFHA0178S0201

- Set the temperature 75°F or 25°C.
- Press OFF switch.
- Turn the ignition off.
- Turn the ignition on.
- Press the AUTO switch.
- Confirm that the set temperature remains at previous temperature.
- Press OFF switch.

If NG, go to trouble diagnosis procedure for memory function (HA-93).

If OK, continue with next check.



SHA398F


2. Check Blower

NFHA0178S0202

- Press fan switch (up side) one time.
Blower should operate on low speed.
The fan symbol should have one blade lit.
- Press fan switch (up side) one more time, and continue checking blower speed and fan symbol until all speeds are checked.
- Leave blower on MAX speed.

If NG, go to trouble diagnosis procedure for blower motor (HA-68).

If OK, continue with next check.



SHA399F






3. Check Discharge Air

NFHA0178S0203

- Press mode switch four times and DEF button.
- Each position indicator should change shape.

Operational Check (Cont'd)

Discharge air flow

Mode control knob	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	80%	20%
	—	60%	40%
	—	—	100%

RHA654F

- Confirm that discharge air comes out according to the air distribution table at left.

Refer to “Discharge Air Flow” (HA-26).

NOTE:

Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF  is selected.


Intake door position is checked in the next step.

If NG, go to trouble diagnosis procedure for mode door motor (HA-56).

If OK, continue with next check.


4. Check Recirculation

NFHA0178S0204

- Press REC  switch.
Recirculation indicator should illuminate.
- Listen for intake door position change (you should hear blower sound change slightly).

If NG, go to trouble diagnosis procedure for intake door (HA-65).

If OK, continue with next check.



SHA400F


5. Check Temperature Decrease

NFHA0178S0205

- Turn the temperature dial counterclockwise until 18°C (65°F) is displayed.
- Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient cooling (HA-82).

If OK, continue with next check.



SHA401F


6. Check Temperature Increase

NFHA0178S0206


- Turn the temperature dial clockwise until 32°C (85°F) is displayed.
- Check for hot air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient heating (HA-90).

If OK, continue with next check.



SHA402F




7. Check ECON (Economy) Mode

NFHA0178S0207

1. Set the temperature 75°F or 25°C.
2. Press ECON switch.
3. Display should indicate ECON (no AUTO).
Confirm that the compressor clutch is not engaged (visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If NG, go to trouble diagnosis procedure for ECON (Economy) mode (HA-94).

If OK, continue with next check.




8. Check AUTO Mode

NFHA0178S0208

1. Press AUTO switch.
2. Display should indicate AUTO (no ECON).
Confirm that the compressor clutch engages (audio or visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If NG, go to trouble diagnosis procedure for A/C system (HA-53), then if necessary, trouble diagnosis procedure for magnet clutch (HA-76).

If OK, continue with next check.




9. Check Ambient Display

NFHA0178S0209

1. Press AMB switch.
2. Display should show the outside (ambient) temperature for approximately 5 seconds.

If NG, go to trouble diagnosis procedure for ambient sensor (HA-95).

If OK, continue with next check.




10. Check Fresh (FRE) Switch (RHD Models)

NFHA0178S0210

1. Press FRE switch.
Fresh indicator should illuminate.
2. Listen for intake door position change (you should hear blower sound change slightly).

If NG, go to trouble diagnosis procedure for intake door (HA-65).

If OK, continue with next check.



11. Check Air Conditioner (A/C) Switch (RHD Models)

NFHA0178S0211

1. Press AUTO switch.
2. Press A/C switch.
A/C indicator will turn OFF.
3. Press A/C switch.
A/C indicator should illuminate and compressor will turn ON.

If all operational check are OK (symptom cannot be duplicated), go to "Incident Simulation Tests" (GI section) and perform tests as outlined to simulate driving conditions environment. If symptom appears, refer to "Symptom Table" (HA-48) and perform applicable trouble diagnosis procedures.

A/C System

TROUBLE DIAGNOSIS PROCEDURE FOR A/C SYSTEM


=NFHA0179

SYMPTOM:

- A/C system does not come on.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – AUTO mode

- a. Press AUTO switch.
- b. Display should indicate AUTO (not ECON). Confirm that the compressor clutch engages (audio or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle, and temperatures switch.)

If OK (symptom cannot be duplicated), perform complete operational check (*2).
 If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

Go to A/C System Circuit. (*3)

OK

4. Replace auto amp.

SHA406F

*1: HA-54

*2: HA-49

*3: HA-54

COMPONENT DESCRIPTION

Automatic Amplifier (Auto Amp.)

NFHA0247

NFHA0247S01

The auto amplifier has a built-in microcomputer which processes information sent from various sensors needed for air conditioner operation. The mode door motor, air mix door motor, intake door motor, blower motor and compressor are then controlled.


The auto amplifier is unitized with control mechanisms. Signals from various switches and Potentio Temperature Control (PTC) are directly entered into auto amplifier.

Self-diagnostic functions are also built into auto amplifier to provide quick check of malfunctions in the auto air conditioner system.


Potentio Temperature Control (PTC)

NFHA0247S02

The PTC is built into the A/C auto amp. It can be set at an interval of 0.5°C (1.0°F) in the 18°C (65°F) to 32°C (85°F) temperature range by pushing the temperature button. The set temperature is digitally displayed.



SHA407F



SHA408F


MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

=NFHA0180

Power Supply Circuit Check

NFHA0180S03

Check power supply circuit for air conditioner system.
Refer to *EL-10*, "Wiring Diagram — POWER —".




DIAGNOSTIC PROCEDURE

SYMPTOM:

- A/C system does not come on.

NFHA0181





1	CHECK POWER SUPPLY CIRCUIT FOR AUTO AMP.											
Measure voltage across terminal Nos. 26, 27, 33 and body ground.												
<div><div><div>Auto amp. connector (M60)</div><div></div></div><div><table><tr><th colspan="2">Votmeter terminal</th><th rowspan="2">Voltage</th></tr><tr><th>(+)</th><th>(-)</th></tr><tr><td>26</td><td rowspan="3">Body ground</td><td rowspan="3">Approx. 12V</td></tr><tr><td>27</td></tr><tr><td>33</td></tr></table></div></div>			Votmeter terminal		Voltage	(+)	(-)	26	Body ground	Approx. 12V	27	33
Votmeter terminal		Voltage										
(+)	(-)											
26	Body ground	Approx. 12V										
27												
33												
OK or NG												
OK	▶	GO TO 2.										
NG	▶	<div>Check auto amp. ground circuit.</div> <div><ul style="list-style-type: none">● Check 10A fuse (Nos. 12 and 19, located in the fuse block) and 15A fuses (Nos. 51 and 52, located in the fuse block).● If fuses are OK, check for open circuit in wiring harness. Repair or replace as necessary.● If fuses are NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.</div>										

SHA319FA

TROUBLE DIAGNOSES

AUTO

A/C System (Cont'd)

2	CHECK BODY GROUND CIRCUIT FOR AUTO AMP.															
Does continuity exist between auto amp. Harness terminal No. 32 and body ground?																
<div><div><div>Auto amp. connector (M60)</div><div></div></div><div><div></div><div></div><div></div></div></div> <table><tr><th colspan="2">Votmeter terminal</th><th rowspan="2">Continuity</th></tr><tr><th>(+)</th><th>(-)</th></tr><tr><td>32</td><td>Body ground</td><td>Yes</td></tr></table> <div>RHA557H</div> <div>Yes or No</div> <table><tr><td>Yes</td><td>▶</td><td>Replace auto amp. INSPECTION END</td></tr><tr><td>No</td><td>▶</td><td>Repair or replace harness.</td></tr></table>			Votmeter terminal		Continuity	(+)	(-)	32	Body ground	Yes	Yes	▶	Replace auto amp. INSPECTION END	No	▶	Repair or replace harness.
Votmeter terminal		Continuity														
(+)	(-)															
32	Body ground	Yes														
Yes	▶	Replace auto amp. INSPECTION END														
No	▶	Repair or replace harness.														

Mode Door Motor

TROUBLE DIAGNOSIS PROCEDURE FOR MODE DOOR MOTOR (LAN)


=NFHA0182

SYMPTOM:

- Air outlet does not change.
- Mode door motor does not operate normally.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Discharge air

- Press mode switch four times and DEF button.
- Each position indicator should change shape.

c. Confirm that discharge air comes out according to the air distribution table at left.


Refer to “Discharge Air Flow” (*1).

NOTE:

- If OK (symptom cannot be duplicated), perform complete operational check (*2).
- If NG (symptom is confirmed), continue with STEP-2 following.
- Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when DEF is selected. Intake door position is checked in the next step.

Discharge air flow

Mode control knob	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	—	80%	20%
	—	60%	40%
	—	—	100%



SHA395F

- *1: HA-26
- *2: HA-49
- *3: HA-38
- *4: HA-39
- *5: HA-94
- *6: HA-97

- *7: HA-101
- *8: HA-107
- *9: FUNCTION CONFIRMATION PROCEDURE (HA-39), see No. 13.
- *10: HA-58

- *11: HA-61
- *12: HA-49
- *13: HA-48
- *14: HA-104

SYSTEM DESCRIPTION

Component Parts


Mode door control system components are:

- 1) Auto amp.
- 2) Mode door motor (LCU)
- 3) In-vehicle sensor
- 4) Ambient sensor
- 5) Sunload sensor
- 6) Intake sensor


System Operation


The auto amplifier receives data from each of the sensors. The amplifier sends mode door, air mix door and intake door opening angle data to the mode door motor LCU, air mix door motor LCU and intake door motor LCU.

The mode door motor, air mix door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/COLD or OPEN/CLOSE or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier.



Mode Door Control Specification





COMPONENT DESCRIPTION


NFHA0184

The mode door motor is attached to the heater unit. It rotates so that air is discharged from the outlet set by the auto amplifier. Motor rotation is conveyed to a link which activates the mode door.

DIAGNOSTIC PROCEDURE FOR MODE DOOR MOTOR, AIR MIX DOOR MOTOR AND INTAKE DOOR MOTOR CIRCUIT

NFHA0185

SYMPTOM: Mode door motor, air mix door motor and/or intake door motor does not operate normally.





1 CHECK POWER SUPPLY FOR AUTO AMP. (LCU) SIDE		
<p>Do approx. 12 volts exist between auto amp. (LCU) harness terminal No. 21 and body ground?</p> <div> </div> <p>NOTE: If the result is NG or No after checking circuit continuity, repair harness or connector.</p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	GO TO 2.
No	▶	Replace auto amp. (LCU).


TROUBLE DIAGNOSES

AUTO

Mode Door Motor (Cont'd)

2	CHECK SIGNAL FOR AUTO AMP. (LCU) SIDE
<p>Do approx. 5.5 volts exist between auto amp. (LCU) terminal No. 16 and body ground?</p> <div style="text-align: center;">  </div> <p>NOTE: If the result is NG or No after checking circuit continuity, repair harness or connector.</p> <p style="text-align: right;">RHA374H</p>	
Yes or No	
Yes	▶ GO TO 3.
No	▶ Replace auto amp. (LCU).






3	CHECK POWER SUPPLY FOR MOTOR SIDE
<p>Do approx. 12 volts exist between door motor (LCU) harness terminal No. 1 and body ground?</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA375HA</p>	
Yes or No	
Yes	▶ GO TO 4.
No	▶ Repair harness or connector.

4	CHECK SIGNAL FOR MOTOR SIDE
<p>Do approx. 5.5 volts exist between door motor (LCU) terminal No. 3 and body ground?</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA376HD</p>	
Yes or No	
Yes	▶ GO TO 5.
No	▶ Repair harness or connector.

TROUBLE DIAGNOSES

AUTO

Mode Door Motor (Cont'd)

5	CHECK MOTOR GROUND CIRCUIT	
Does continuity exist between door motor (LCU) harness terminal No. 2 and body ground?		
<div><div></div><div>Mode door motor connector (M49), air mix door motor connector (M51) or Intake door motor (M84)</div></div> <div></div>		
Yes or No		
Yes	▶	GO TO 6.
No	▶	Repair harness or connector.

RHA377HA

6	CHECK MOTOR OPERATION	
Disconnect and reconnect the motor connector and confirm the motor operation.		
OK or NG		
OK (Return to operate normally.)	▶	Poor contacting the motor connector
NG (Does not operate normally.)	▶	GO TO 7.

7	CHECK MODE DOOR MOTOR AND INTAKE DOOR MOTOR OPERATION	
1. Disconnect the mode door motor and air mix door motor connector. 2. Reconnect the mode door motor and confirm the mode door and intake door motor operation.		
OK or NG		
OK (Mode door motor and intake door motor operate normally.)	▶	Replace the air mix door motor.
NG (Mode door motor and intake door motor do not operate normally.)	▶	GO TO 8.


8	CHECK MODE DOOR MOTOR AND AIR MIX DOOR MOTOR OPERATION	
1. Disconnect the intake door motor connector. 2. Reconnect the air mix door motor and confirm the mode door and air mix door motor operation.		
OK or NG		
OK (Mode door motor and air mix door motor operate normally.)	▶	Replace intake door motor.
NG (Mode door motor and air mix door motor do not operate normally.)	▶	GO TO 9.

TROUBLE DIAGNOSES

AUTO

Mode Door Motor (Cont'd)

9	CHECK AIR MIX DOOR MOTOR AND INTAKE DOOR MOTOR OPERATION	
1. Disconnect the mode door motor connector. 2. Reconnect the intake door motor and confirm the air mix door and intake door motor operation.		
OK or NG		
OK (Air mix door motor and intake door motor operate normally.)	▶	Replace mode door motor.
NG (Air mix door motor and intake door motor do not operate normally.)	▶	Replace auto amp.



CONTROL LINKAGE ADJUSTMENT

NFHA0186

Mode Door

NFHA0186S01

1. Install mode door motor on heater unit and connect it to main harness.
2. Set up code No. in Self-diagnosis STEP 4. Refer to HA-39.
3. Move side link by hand and hold mode door in DEF mode.
4. Attach mode door motor rod to side link rod holder.
5. Make sure mode door operates properly when changing from code No. 41 to 45 by pushing DEF switch.

41	42	43	44	45	46
VENT	B/L	B/L	FOOT	D/F	DEF

Air Mix Door Motor

TROUBLE DIAGNOSIS PROCEDURE FOR AIR MIX DOOR (LAN)


=NFHA0187

SYMPTOM:

- Discharge air temperature does not change.
- Air mix door motor does not operate.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK



Temperature increase

- Turn the temperature dial clockwise until 32°C (85°F) is displayed.
- Check for hot air at discharge air outlets.

Temperature decrease

- Turn the temperature dial counterclockwise until 18°C (65°F) is displayed.
- Check for cold air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*10).
If NG (symptom is confirmed), continue with STEP-2 following.



*1: HA-38

*2: HA-94

*3: HA-97

*4: HA-101

*5: HA-107

*6: FUNCTION CONFIRMATION
PROCEDURE (HA-39), see No.
13.

*7: HA-58

*8: HA-64

*9: HA-64

*10: HA-49

*12: HA-49

*13: HA-48

*14: HA-104

*15: HA-39

Another symptom exists.

SHA409F

SYSTEM DESCRIPTION


Component Parts

Air mix door control system components are:


- 1) Auto amp.
- 2) Air mix door motor (LCU)
- 3) In-vehicle sensor
- 4) Ambient sensor
- 5) Sunload sensor
- 6) Intake sensor

System Operation


The auto amplifier receives data from each of the sensors. The amplifier sends mode door, air mix door, intake door opening angle data to the mode door motor LCU, air mix door motor LCU and intake door motor LCU. The mode door motor, air mix door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/COLD or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier.



Air Mix Door Control Specification



Air Mix Door Motor (Cont'd)



COMPONENT DESCRIPTION

NFHA0189



The air mix door motor is attached to the heater unit. It rotates so that the air mix door is opened or closed to a position set by the auto amplifier. Motor rotation is then conveyed through a shaft and the air mix door position is then fed back to the auto amplifier by PBR built-in air mix door motor.

DIAGNOSTIC PROCEDURE

NFHA0248

SYMPTOM: Discharge air temperature does not change.

- Refer to HA-58.



CONTROL LINKAGE ADJUSTMENT

NFHA0190

Air Mix Door

NFHA0190S01

- Install air mix door motor on heater unit and connect it to main harness.
- Set up code No. 41 in Self-diagnosis STEP 4. Refer to HA-38.
- Move air mix door lever by hand and hold it in full cold position.
- Attach air mix door lever to rod holder.
- Make sure air mix door operates properly when changing from code No. 41 to 46 by pushing DEF switch.

41	42	43	44	45	46
Full cold		Full hot			

Intake Door Motor


TROUBLE DIAGNOSIS PROCEDURE FOR INTAKE DOOR (LAN)

NFHA0191

SYMPTOM:

- Intake door does not change.
- Intake door motor does not operate normally.

INSPECTION FLOW



SHA410F

- *1: HA-38
*2: HA-94
*3: HA-97
*4: HA-101
*5: HA-107

- *6: FUNCTION CONFIRMATION
PROCEDURE (HA-39), see No.
13.
- *7: HA-67
- *8: HA-67

- *9: HA-49
*10: HA-39
*11: HA-49
*12: HA-48
*13: HA-104

SYSTEM DESCRIPTION**Component Parts**

Intake door control system components are:

- 1) Auto amp.
- 2) Intake door motor (LCU)
- 3) In-vehicle sensor
- 4) Ambient sensor
- 5) Sunload sensor
- 6) Intake sensor

=NFHA0192


NFHA0192S01

System Operation

NFHA0192S02

The auto amplifier receives data from each of the sensors. The amplifier sends mode door, air mix door, intake door opening angle data to the mode door motor LCU, air mix door motor LCU and intake door motor LCU.


The mode door motor, air mix door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/COLD or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier. When the ECON, DEFROST, or OFF switches are pushed, the auto amplifier sets the intake door at the "Fresh" position.




RHA382HD

Intake Door Control Specification

NFHA0192S03



RHA383H



COMPONENT DESCRIPTION

NFHA0193


The intake door motor is attached to the intake unit. It rotates so that air is drawn from inlets set by the auto amplifier. Motor rotation is conveyed to a lever which activates the intake door.

DIAGNOSTIC PROCEDURE

NFHA0194

SYMPTOM: Intake door motor does not operate normally.

- Refer to HA-58.



CONTROL LINKAGE ADJUSTMENT

NFHA0195

Intake Door

NFHA0195S01

1. Install intake door motor on intake unit and connect it to main harness.
2. Set up code No. 41 in Self-diagnosis STEP 4. Refer to HA-39.
3. Make sure intake door operates properly when changing from code No. 41 to 46 by pushing DEF switch.

41	42	43	44	45	46
REC		20% FRE	FRE		

Blower Motor


TROUBLE DIAGNOSIS PROCEDURE FOR BLOWER MOTOR

=NFHA0196

SYMPTOM:

- Blower motor operation is malfunctioning.
- Blower motor operation is malfunctioning under out of starting fan speed control.

INSPECTION FLOW



SHA411F

*1: HA-38

*2: HA-94

*3: HA-97

*4: HA-101

*5: HA-107

*6: FUNCTION CONFIRMATION
PROCEDURE (HA-39), see No.
13.

*7: HA-71

*8: HA-71

*9: HA-39

*10: HA-49

*11: HA-48

*12: HA-49

*13: HA-104

*14: **EL-138**


SYSTEM DESCRIPTION

Component parts

Fan speed control system components are:

- 1) Auto amp.
- 2) Fan control amp.
- 3) A/C LAN system (PBR built-in air mix door motor, mode door motor and intake door motor)
- 4) In-vehicle sensor
- 5) Ambient sensor
- 6) Sunload sensor
- 7) Intake sensor

System Operation



Automatic Mode

In the automatic mode, the blower motor speed is calculated by the automatic amplifier based on inputs from the PBR, in-vehicle sensor, sunload sensor, intake sensor and ambient sensor. The blower motor applied voltage ranges from approximately 5 volts (lowest speed) to 12 volts (highest speed).

The control blower speed (in the range of 5 to 12V), the automatic amplifier supplies a gate voltage to the fan control amplifier. Based on this voltage, the fan control amplifier controls the voltage supplied to the blower motor.

Starting Fan Speed Control

Start Up From "COLD SOAK" Condition (Automatic mode)

In a cold start up condition where the engine coolant temperature is below 50°C (122°F), the blower will not operate for a short period of time (up to 126 seconds). The exact start delay time varies depending on the ambient and engine coolant temperature.

In the most extreme case (very low ambient) the blower starting delay will be 126 seconds as described above. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 55°C (131°F), at which time the blower speed will increase to the objective speed.

Start Up From Normal or "HOT SOAK" Condition (Automatic mode)

NFHA0197S0402

The blower will begin operation momentarily after the AUTO button is pushed. The blower speed will gradually rise to the objective speed over a time period of 3 seconds or less (actual time depends on the objective blower speed).

Blower Speed Compensation
Sunload

NFHA0197S05


NFHA0197S0501

When the in-vehicle temperature and the set temperature are very close, the blower will be operating at low speed. The low speed will vary depending on the sunload. During conditions of high sunload, the blower low speed is "normal" low speed (approx. 6V). During low or no sunload conditions, the low speed will drop to "low" low speed (approx. 5V).

Ambient


NFHA0197S0502

When the ambient temperature is in the "moderate" range [10 - 15°C (50 - 59°F)], the computed blower voltage will be compensated (reduced) by up to 3.5V (depending on the blower speed). In the "extreme" ambient ranges [below 0°C (32°F) and above 20°C (68°F)] the computed objective blower voltage is not compensated at all. In the ambient temperature ranges between "moderate" and "extreme" [0 - 10°C (32 - 50°F) and 15 - 20°C (59 - 68°F)], the amount of compensation (for a given blower speed) varies depending on the ambient temperature.



Fan Speed Control Specification

NFHA0197S06



COMPONENT DESCRIPTION

NFHA0198

Fan Control Amplifier


NFHA0198S01

The fan control amplifier is located on the cooling unit. The fan control amp. receives a gate voltage from the auto amp. to steplessly maintain the blower fan motor voltage in the 5 to 12 volt range (approx.).

TROUBLE DIAGNOSES

AUTO

Blower Motor (Cont'd)



DIAGNOSTIC PROCEDURE

NFHA0199

SYMPTOM: Blower motor operation is malfunctioning under Starting Fan Speed Control.



1	CHECK POWER SUPPLY FOR FAN CONTROL AMP.	
Disconnect fan control amp. harness connector. Do approx. 12 volts exist between fan control amp. harness terminal No. 1 and body ground?		
<div><div>Fan control amp. connector (M31)</div><div><div>1</div><div>L/W</div></div><div><div>V</div><div>+</div><div>-</div></div><div><div>H.S.</div><div>DISCONNECT</div><div>ON</div></div></div> <div>RHA392H</div>		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 8.

2	CHECK BODY GROUND CIRCUIT FOR FAN CONTROL AMP.	
Does continuity exist between fan control amp. harness terminal No. 3 and body ground?		
<div><div>Fan control amp. connector (M31)</div><div><div>3</div><div>B</div></div><div><div>Ω</div></div><div><div>H.S.</div><div>DISCONNECT</div><div>OFF</div></div></div> <div>RHA393H</div>		
Yes or No		
Yes	▶	Reconnect fan control amp. harness connector. And GO TO 3.
No	▶	Repair harness or connector.



TROUBLE DIAGNOSES

AUTO


Blower Motor (Cont'd)


3	CHECK FOR AUTO AMP. OUTPUT											
<p>Set up Self-diagnosis STEP 4. Measure voltage across fan control amp. harness terminal No. 2 and body ground.</p>												
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Fan control amp. connector (M31)</p> <p>Self-diagnosis STEP 4</p> <p>41-45</p> </div> <div style="text-align: center;"> <p>CONNECT</p>  </div> </div>												
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Code No.</th> <th colspan="2">Terminal No.</th> <th rowspan="2">Voltage</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>41-45</td> <td>(2)</td> <td>Body ground</td> <td>Approx. 2.5 - 3V</td> </tr> </tbody> </table>			Code No.	Terminal No.		Voltage	(+)	(-)	41-45	(2)	Body ground	Approx. 2.5 - 3V
Code No.	Terminal No.			Voltage								
	(+)	(-)										
41-45	(2)	Body ground	Approx. 2.5 - 3V									
SHA321FA												
OK or NG												
OK	▶	GO TO 4.										
NG	▶	<ul style="list-style-type: none"> The result is less than 2.5V. Replace fan control amp. The result is more than 3.0V. GO TO 4. 										

4	CHECK FAN CONTROL AMP.	
Refer to HA-75.		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Replace fan control amp.

5	CHECK FAN CONTROL AMP. CIRCUIT BETWEEN FAN CONTROL AMP. AND AUTO AMP. (LCU)	
<p>1. Disconnect auto amp. (LCU) and fan control amp. harness connector. 2. Check circuit continuity between auto amp. (LCU) harness terminal No. 35 and fan control amp. harness terminal No. 2.</p>		
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Fan control amp. connector (M31)</p> <p>Auto amp. connector (M60)</p> <p>35</p> <p>L/Y</p> </div> <div style="text-align: center;"> <p>DISCONNECT</p>  </div> </div>		
<p>Continuity should exist. If OK, check harness for short.</p>		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair harness or connector.

RHA559H

6 CHECK FAN FEED BACK CIRCUIT		
Reconnect auto amp. (LCU) harness connector. Do approx. 12 volts exist between auto amp. (LCU) harness terminal No. 33 and body ground?		
 <div style="text-align: right;">RHA560H</div>		
Yes or No		
Yes	►	GO TO 7.
No	►	Check power supply circuit and 15A fuses (Nos. 51 and 52, located in the fuse block). Refer to EL-10 , "Wiring Diagram — POWER —". <ul style="list-style-type: none"> • If OK, check for open circuit in wiring harness. Repair or replace as necessary. • If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.

7 CHECK POWER SUPPLY FOR AUTO AMP.		
Do approx. 12 volts exist between auto amp. harness terminal No. 34 and body ground?		
 <div style="text-align: right;">RHA561H</div>		
Yes or No		
Yes	►	1. Replace auto amp. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-4. Confirm that blower motor operation is normal.
No	►	GO TO 10.

Blower Motor (Cont'd)

8	CHECK POWER SUPPLY FOR BLOWER MOTOR	
Disconnect blower motor harness connector. Do approx. 12 volts exist between blower motor harness terminal No. 1 and body ground?		<div data-bbox="598 358 997 649"> </div> <div data-bbox="1356 638 1460 672">RHA091GE</div> <p data-bbox="734 683 861 716">Yes or No</p>
Yes	▶	GO TO 9.
No		<p data-bbox="494 772 1460 828">Check power supply circuit and 15A fuses (Nos. 51 and 52, located in the fuse block).</p> <ul data-bbox="494 828 1460 974" style="list-style-type: none"> • Check blower motor relay. • If OK, check for open circuit in wiring harness. Repair or replace as necessary. • If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.

9	CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND FAN CONTROL AMP.	
Disconnect blower motor connector and auto amp. (LCU) connector. Check circuit continuity between blower motor harness terminal No. 2 and fan control amp. harness terminal No. 1.		<div data-bbox="598 1142 997 1433"> </div> <div data-bbox="1356 1411 1460 1444">RHA397H</div> <p data-bbox="159 1433 446 1467">Continuity should exist.</p> <p data-bbox="127 1467 470 1500">If OK, check harness for short.</p> <p data-bbox="734 1512 861 1545">OK or NG</p>
OK	▶	<p data-bbox="494 1556 1460 1590">Check blower motor. (Refer to HA-75.)</p> <ol data-bbox="494 1590 1460 1702" style="list-style-type: none"> 1. If NG, replace blower motor. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-4. Confirm that blower motor operation is normal.
NG	▶	Repair harness or connector.


TROUBLE DIAGNOSES


AUTO


Blower Motor (Cont'd)


10
CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND AUTO AMP. (LCU)

Check circuit continuity between blower motor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 34.


DISCONNECT


Blower motor connector (E102)


Auto amp. connector (M60)



RHA562H

Continuity should exist.


If OK, check harness for short.

OK or NG

NG

▶

Repair harness or connector.



COMPONENT INSPECTION


Blower Motor

Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.

NFHA0200

NFHA0200S01



Fan Control Amp.

Check circuit continuity between terminals.

NFHA0200S02

Terminal Nos.	Continuity
2 - 3	Yes

Magnet Clutch


TROUBLE DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH

=NFHA0201

SYMPTOM:

- Magnet clutch does not engage.

INSPECTION FLOW



SHA412F

*1: FUNCTION CONFIRMATION
PROCEDURE (HA-39)

*2: HA-94

*3: HA-97

*4: HA-101

*5: HA-107

*6: FUNCTION CONFIRMATION
PROCEDURE (HA-39), see No.
13.

*7: HA-77

*8: HA-85

*9: HA-49

*10: HA-39

*11: HA-49


*12: HA-48

*13: HA-104

TROUBLE DIAGNOSES

AUTO

Magnet Clutch (Cont'd)



SYSTEM DESCRIPTION

=NFHA0202


Auto amplifier controls compressor operation by ambient temperature and signal from ECM.

Low Temperature Protection Control

NFHA0202S01

Auto amplifier will turn the compressor “ON” or “OFF” as determined by a signal detected by ambient sensor.

When ambient temperatures are greater than -2°C (28°F), the compressor turns “ON”. The compressor turns “OFF” when ambient temperatures are less than -5°C (23°F).



DIAGNOSTIC PROCEDURE

NFHA0203

SYMPTOM: Magnet clutch does not engage when **AUTO** switch is ON.

1 CHECK POWER SUPPLY FOR COMPRESSOR		
Disconnect compressor harness connector. Do approx. 12 volts exist between compressor harness terminal No. 1 and body ground?		
<div></div>		
Yes or No		
Yes	►	Check magnet clutch coil. 1. If NG, replace magnet clutch. Refer to HA-113. 2. Go to “FUNCTION CONFIRMATION PROCEDURE”, “Self-diagnosis”, HA-39 and perform self-diagnosis STEP-4. Confirm that magnet clutch operation is normal.
No	►	Disconnect A/C relay. And GO TO 2.

2	CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND COMPRESSOR
<p>Check circuit continuity between A/C relay harness terminal No. 3 and compressor harness terminal No. 1.</p> <div style="text-align: center;"> <p>Compressor connector (A3) A/C relay connector (E71)</p> <p>B/P Y/B</p> </div> <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> <p style="text-align: right;">RHA400H</p>	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair harness or connector.

3	CHECK POWER SUPPLY FOR A/C RELAY
<p>Disconnect A/C relay.</p> <p>Do approx. 12 volts exist between A/C relay harness terminal Nos. 1, 5 and body ground?</p> <div style="text-align: center;"> <p>A/C relay connector (E71)</p> <p>LG P</p> </div> <p style="text-align: right;">RHA401HA</p>	
Yes or No	
Yes	▶ GO TO 4.
No	<p>▶ Check power supply circuit and 10A (Nos. 19, 66) fuse at fuse block. Refer to EL-10, "Wiring Diagram — POWER —".</p> <ul style="list-style-type: none"> • If OK, check for open circuit in wiring harness. Repair or replace as necessary. • If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.







4	CHECK A/C RELAY AFTER DISCONNECTING IT
<p>Refer to HA-81.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Reconnect A/C relay. And GO TO 5.
NG	<p>▶ 1. Replace A/C relay.</p> <p>2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-4.</p> <p>Confirm that magnet clutch operation is normal.</p>


TROUBLE DIAGNOSES

AUTO


Magnet Clutch (Cont'd)


5	CHECK COIL SIDE CIRCUIT OF A/C RELAY	
Do approx. 12 volts exist between ECM harness terminal No. 27 and body ground?		
<div><div><div>ECM connector (F48)</div><div><div>ECM</div><div>CONNECTOR</div></div><div>27</div></div><div><div>BR</div><div>V</div><div>+</div><div>-</div></div><div><div><div><div><div>H.S.</div><div>CONNECT</div></div><div><div>ON</div><div>A/C</div></div></div></div></div><div><div><div><div><div>H.S.</div><div>CONNECT</div></div><div><div>ON</div><div>A/C</div></div></div></div></div></div>		
RHA482GD		
Yes or No		
Yes	▶	GO TO 6.
No	▶	Disconnect A/C relay. Disconnect ECM harness connector. GO TO 9.

6	CHECK VOLTAGE FOR ECM	
Do approx. 12 volts exist between ECM harness terminal No. 45 and body ground?		
<div><div><div> H.S.</div><div> CONNECT</div><div> ON</div><div> A/C</div></div><div>ECM connector (F48)</div><div><div>ECM</div><div>CONNECTOR</div></div><div><div>45</div><div>GB</div><div></div><div></div></div></div>		
RHA701FG		
Yes or No		
Yes	▶	Disconnect ECM harness connector. Disconnect refrigerant pressure sensor harness connector. GO TO 7.
No	▶	Check ECM. Refer to EC-119 , “ECM Terminals and Reference Value”.

7 CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL		
Do approx. 0 volts exist between ECM harness terminal No. 51 and ground?		
<div style="text-align: center;">  </div>		
RHA402H		
Yes or No		
Yes	▶	GO TO 8.
No	▶	1. Repair harness or connector. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-4. Confirm that magnet clutch operation is normal.

8 CHECK REFRIGERANT PRESSURE SENSOR		
Refer to HA-81.		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Replace refrigerant pressure sensor.

9 CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND ECM		
Check circuit continuity between A/C relay harness terminal No. 2 and ECM harness terminal No. 27.		
<div style="text-align: center;">  </div>		
RHA403H		
Continuity should exist. If OK, check harness for short.		
OK or NG		
OK	▶	Check ECM. Refer to EC-119 , "ECM Terminals and Reference Value".
NG	▶	Repair harness or connector. Replace auto amp.



COMPONENT INSPECTION

A/C Relay


NFHA0204

NFHA0204S01

Check continuity between terminal Nos. 3 and 5.

Conditions	Continuity
12V direct current supply between terminal Nos. 1 and 2	Yes
No current supply	No


If NG, replace relay.



Refrigerant Pressure Sensor

NFHA0204S02

Make sure that higher A/C refrigerant pressure results in higher refrigerant-pressure sensor output voltage.



Insufficient Cooling


TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING

=NFHA0205

SYMPTOM:

- Insufficient cooling

INSPECTION FLOW



SHA396F

*1: HA-38

*2: HA-64

*3: HA-85

*4: HA-47

*5: FUNCTION CONFIRMATION
PROCEDURE (HA-39), see No.
13.

*6: HA-57

*7: HA-69

*8: HA-77

*9: HA-83


*10: HA-49

*11: HA-39

*12: **MA-15***13: **EC-366**

PERFORMANCE TEST DIAGNOSES

NFHA0206




SHA344F

*1: HA-85

*3: HA-86

*4: HA-63

*2: HA-85



SHA329F

*1: HA-113

*2: HA-68

*3: **MA-15**

TROUBLE DIAGNOSES

AUTO

Insufficient Cooling (Cont'd)




PERFORMANCE TEST

Test Condition

NFHA0207

NFHA0207S01

Testing must be performed as follows:

Vehicle location	Indoors or in the shade (in a well-ventilated place)
Doors	Closed
Door windows	Open
Hood	Open
TEMP.	Max. COLD
Mode switch	 (Ventilation) set
REC switch	 (Recirculation) set
 (blower) speed	Max. speed set
Engine speed	Idle speed

Operate the air conditioning system for 10 minutes before taking measurements.

Test Reading

Recirculating-to-discharge Air Temperature Table

NFHA0207S02

NFHA0207S0201

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	15 (59)	3.5 - 5.4 (38 - 42)
	20 (68)	6.6 - 8.9 (44 - 48)
	25 (77)	9.5 - 12.6 (49 - 55)
	30 (86)	13.4 - 16.5 (56 - 62)
	35 (95)	17.6 - 21.3 (64 - 70)
60 - 70	15 (59)	5.4 - 7.1 (42 - 45)
	20 (68)	8.9 - 11.0 (48 - 52)
	25 (77)	12.6 - 15.4 (55 - 60)
	30 (86)	16.5 - 20.0 (62 - 68)
	35 (95)	21.3 - 24.8 (70 - 77)

Ambient Air Temperature-to-operating Pressure Table

NFHA0207S0202

Ambient air		High-pressure (Discharge side) kPa (bar, kg/cm ² , psi)	Low-pressure (Suction side) kPa (bar, kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	15 (59)	539 - 657 (5.39 - 6.57, 5.5 - 6.7, 78 - 95)	177 - 216 (1.77 - 2.16, 1.8 - 2.2, 26 - 31)
	20 (68)	677 - 824 (6.77 - 8.24, 6.9 - 8.4, 98 - 119)	167 - 206 (1.67 - 2.06, 1.7 - 2.1, 24 - 30)
	25 (77)	843 - 1,030 (8.43 - 10.30, 8.6 - 10.5, 122 - 149)	177 - 226 (1.77 - 2.26, 1.8 - 2.3, 26 - 33)
	30 (86)	1,030 - 1,275 (10.30 - 12.75, 10.5 - 13.0, 149 - 185)	216 - 255 (2.16 - 2.55, 2.2 - 2.6, 31 - 37)
	35 (95)	1,245 - 1,520 (12.45 - 15.20, 12.7 - 15.5, 181 - 220)	265 - 324 (2.65 - 3.24, 2.7 - 3.3, 38 - 47)


TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE

NFHA0208

Whenever system's high and/or low side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (normal) pressure range. Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-85 ("Ambient air temperature-to-operating pressure table").

Both High and Low-pressure Sides are Too High.

NFHA0208S01

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high and low-pressure sides are too high.</p> <p>A</p>  <p>AC359A</p>	<ul style="list-style-type: none"> Pressure is reduced soon after water is splashed on condenser. 	Excessive refrigerant charge in refrigeration cycle	Reduce refrigerant until specified pressure is obtained.
	Air suction by cooling fan is insufficient.	<p>Insufficient condenser cooling performance</p> <p>↓</p> <ol style="list-style-type: none"> Condenser fins are clogged. Improper fan rotation of cooling fan 	<ul style="list-style-type: none"> Clean condenser. Check and repair cooling fan as necessary.
	<ul style="list-style-type: none"> Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (1.96 bar, 2 kg/cm², 28 psi). It then decreases gradually thereafter. 	<p>Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.)</p> <p>↓</p> <p>Air in refrigeration cycle</p>	Evacuate repeatedly and recharge system.
	Engine tends to overheat.	Engine cooling systems malfunction.	Check and repair each engine cooling system.
	<ul style="list-style-type: none"> An area of the low-pressure pipe is colder than areas near the evaporator outlet. Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> Excessive liquid refrigerant on low-pressure side Excessive refrigerant discharge flow Expansion valve is open a little compared with the specification. <p>↓</p> <ol style="list-style-type: none"> Improper thermal valve installation Improper expansion valve adjustment 	Replace expansion valve.


TROUBLE DIAGNOSES

AUTO

Insufficient Cooling (Cont'd)


High-pressure Side is Too High and Low-pressure Side is Too Low.

NFHA0208S02

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p>AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> Check and repair or replace malfunctioning parts. Check lubricant for contamination.


High-pressure Side is Too Low and Low-pressure Side is Too High.

NFHA0208S03

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p>AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p>↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>
	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor pressure operation is improper.</p> <p>↓</p> <p>Damaged inside compressor packings.</p>	<p>Replace compressor.</p>

Both High- and Low-pressure Sides are Too Low.

NFHA0208S04

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p style="text-align: right;">AC353A</p>	<ul style="list-style-type: none"> There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. Liquid tank inlet and expansion valve are frosted. 	Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)	<ul style="list-style-type: none"> Replace liquid tank. Check lubricant for contamination.
	<ul style="list-style-type: none"> Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. Expansion valve inlet may be frosted. Temperature difference occurs somewhere in high-pressure side 	High-pressure pipe located between receiver drier and expansion valve is clogged.	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	<ul style="list-style-type: none"> Expansion valve and liquid tank are warm or only cool when touched. 	Low refrigerant charge ↓ Leaking fittings or components	Check refrigerant for leaks. Refer to "Checking Refrigerant Leaks", HA-121.
	There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.	Expansion valve closes a little compared with the specification. ↓ 1. Improper expansion valve adjustment 2. Malfunctioning thermal valve 3. Outlet and inlet may be clogged.	<ul style="list-style-type: none"> Remove foreign particles by using compressed air. Check lubricant for contamination.
	An area of the low-pressure pipe is colder than areas near the evaporator outlet.	Low-pressure pipe is clogged or crushed.	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	Air flow volume is not enough or is too low.	Evaporator is frozen. ↓ Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)	Replace compressor.


TROUBLE DIAGNOSES

AUTO

Insufficient Cooling (Cont'd)


Low-pressure Side Sometimes Becomes Negative.

NFHA0208S05

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p style="text-align: right;">AC354A</p>	<ul style="list-style-type: none"> • Air conditioning system does not function and does not cyclically cool the compartment air. • The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> • Drain water from refrigerant or replace refrigerant. • Replace liquid tank.

Low-pressure Side Becomes Negative.

NFHA0208S06

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p>F</p>  <p style="text-align: right;">AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> • If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. • If due to foreign particles, remove expansion valve and remove the particles with dry and compressed air (not shop air). • If either of the above methods cannot correct the problem, replace expansion valve. • Replace liquid tank. • Check lubricant for contamination.

Insufficient Heating


TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT HEATING

=NFHA0209

SYMPTOM:

- Insufficient heating

INSPECTION FLOW



SHA416F

- *1: HA-49
- *2: HA-38
- *3: HA-39
- *4: HA-39
- *5: HA-64

- *6: FUNCTION CONFIRMATION PROCEDURE (HA-39), see No. 13.
- *7: HA-58
- *8: HA-71

- *9: HA-62
- *10: **LC-16**
- *11: **MA-16**
- *12: **MA-16**
- *13: **LC-11**


Noise

TROUBLE DIAGNOSIS PROCEDURE FOR NOISE

SYMPTOM:

- Noise

=NFHA0210



*1: HA-113

*2: HA-115

*3: HA-110

*4: HA-49

*5: **MA-15**

Self-diagnosis


TROUBLE DIAGNOSIS PROCEDURE FOR SELF-DIAGNOSIS

=NFHA0211

SYMPTOM:

- Self-diagnosis cannot be performed.

INSPECTION FLOW



*1: HA-54

*2: HA-94

*3: HA-97

*4: HA-101

*5: HA-104

*6: HA-107

*7: HA-49

*8: HA-48

*9: HA-49

SHA413F

Memory Function

TROUBLE DIAGNOSIS PROCEDURE FOR MEMORY FUNCTION


=NFHA0212

SYMPTOM:

- Memory function does not operate.

INSPECTION FLOW

- Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Memory function

- Set the temperature 75°F or 25°C.
- Press OFF switch.
- Turn the ignition off.
- Turn the ignition on.
- Press the AUTO switch.
- Confirm that the set temperature remains at previous temperature.
- Press OFF switch.

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

- Check for any service bulletins.

- Check Main Power Supply and Ground Circuit. (*1)

OK

Go to A/C system circuit. (*4)

OK

- Replace auto amp.

- FINAL CHECK

Go to self-diagnosis step-by-step procedure (*3) and perform self-diagnosis STEP-2.
Confirm that code No. 20 is displayed.

SHA414F

*1: HA-54

*3: HA-39

*4: HA-54

*2: HA-49

ECON (ECONOMY) Mode

TROUBLE DIAGNOSIS PROCEDURE FOR ECON (ECONOMY) MODE


=NFHA0213

SYMPTOM:

- ECON mode does not operate.

INSPECTION FLOW

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – ECON (ECONOMY) mode

- a. Set the temperature 75°F or 25°C.
- b. Press ECON switch.
- c. Display should indicate ECON (not AUTO).
Confirm that the compressor clutch is not engaged (visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle, and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

Go to A/C system circuit. (*4)

OK

4. Replace auto amp.

5. FINAL CHECK

Go to self-diagnosis step-by-step procedure (*3) and perform self-diagnosis STEP-2.

Confirm that code No. 20 is displayed.


SHA415F

*1: HA-54

*3: HA-39

*4: HA-54

*2: HA-49



RHA410H

Ambient Sensor Circuit

COMPONENT DESCRIPTION

The ambient sensor is attached in front of the right side condenser. It detects ambient temperature and converts it into a resistance value which is then input into the auto amplifier.

NFHA0214

AMBIENT TEMPERATURE INPUT PROCESS


NFHA0215

The automatic amplifier includes a “processing circuit” for the ambient sensor input. However, when the temperature detected by the ambient sensor increases quickly, the processing circuit retards the auto amp. function. It only allows the auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds. As an example, consider stopping for a cup of coffee after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the ambient sensor will increase. This is because the heat from the engine compartment can radiate to the front grille area, location of the ambient sensor.


DIAGNOSTIC PROCEDURE

NFHA0216

SYMPTOM: Ambient sensor circuit is open or shorted. ($\overline{2}$ 1 or $\overline{2}$ 1 is indicated on the display as a result of conducting Self-diagnosis STEP 2.)



1 CHECK VOLTAGE BETWEEN AMBIENT SENSOR HARNESS CONNECTOR AND BODY GROUND		
Disconnect ambient sensor harness connector. Do approx. 5 volts exist between ambient sensor harness terminal No. 1 and body ground?		
<div> <div> <div>Ambient sensor connector</div> <div>E55</div> </div> <div> <div>OR/B</div> <div>1</div> </div> <div> <div>V</div> <div>+</div> <div>-</div> </div> <div> <div>DISCONNECT</div> <div>T.S.</div> <div>ON</div> </div> </div> <div> <div>Yes or No</div> </div>		
Yes	▶	GO TO 2.
No	▶	GO TO 4.



COMPONENT INSPECTION

NFHA0217


Ambient Sensor

NFHA0217S01

After disconnecting ambient sensor harness connector, measure resistance between terminals 2 and 1 at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace ambient sensor.



In-vehicle Sensor Circuit

NFHA0218


COMPONENT DESCRIPTION

In-vehicle sensor

NFHA0218S01

The in-vehicle sensor is located on instrument lower panel. It converts variations in temperature of compartment air drawn from the aspirator into a resistance value. It is then input into the auto amplifier.



In-vehicle Sensor Circuit (Cont'd)



Aspirator

The aspirator is located in front of heater unit. It produces vacuum pressure due to air discharged from the heater unit, continuously taking compartment air in the aspirator.

NFHA0218S02







DIAGNOSTIC PROCEDURE

SYMPTOM: In-vehicle sensor circuit is open or shorted. (?? or -?? is indicated on the display as a result of conducting Self-diagnosis STEP 2.)

NFHA0219


1 CHECK IN-VEHICLE SENSOR CIRCUIT BETWEEN IN-VEHICLE SENSOR AND BODY GROUND		
Disconnect in-vehicle sensor harness connector. Do approx. 5 volts exist between in-vehicle sensor harness terminal No. 1 and body ground?		
<div> <div> <div>In-vehicle sensor (M44)</div> <div> </div> <div>DISCONNECT</div> <div> </div> </div> <div> </div> </div>		
SHA318F		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 4.

2	CHECK IN-VEHICLE SENSOR CIRCUIT BETWEEN IN-VEHICLE SENSOR AND AUTO AMP. (LCU)	
<div>1. Disconnect auto amp. (LCU) harness connector.</div> <div>2. Check circuit continuity between in-vehicle sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11.</div> <div>3. Check circuit continuity between in-vehicle sensor harness terminal No. 2 and body ground.</div>		
<div><div><div><div><div></div><div>H.S.</div></div><div><div></div><div>DISCONNECT</div></div><div><div></div><div>OFF</div></div></div><div><div>Auto amp. (LCU) connector (M59)</div><div>In-vehicle sensor (M44)</div><div>In-vehicle sensor connector (M44)</div></div><div></div></div></div>		
<div>Continuity should exist.</div> <div>If OK, check harness for short.</div> <div>RHA814H</div>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness or connector.

3	CHECK IN-VEHICLE SENSOR	
Refer to HA-100.		
OK or NG		
OK	▶	1. Replace auto amp. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
NG	▶	1. Replace in-vehicle sensor. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

4	CHECK IN-VEHICLE SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND AUTO AMP. (LCU)
1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between in-vehicle sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 3.	
<div> </div>	
<p>Continuity should exist. If OK, check harness for short.</p>	
<p style="text-align: center;">OK or NG</p>	
OK	1. Replace auto amp. (LCU). 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
NG	Repair harness or connector.

RHA479GC



RHA414H

COMPONENT INSPECTION

In-vehicle Sensor

After disconnecting in-vehicle sensor harness connector, measure resistance between terminals 1 and 2 at sensor harness side, using the table below.

NFHA0220

NFHA0220S01


Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace in-vehicle sensor.

Sunload Sensor Circuit COMPONENT DESCRIPTION

NFHA0221

The sunload sensor is located on the right defroster grille. It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the auto amplifier.




SUNLOAD INPUT PROCESS

NFHA0222

The auto amp. also includes a processing circuit which “average” the variations in detected sunload over a period of time. This prevents drastic swings in the ATC system operation due to small or quick variations in detected sunload.






For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor will vary whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the ATC system operation. On the other hand, shortly after entering a long tunnel, the system will recognize the change in sunload, and the system will react accordingly.






Sunload Sensor Circuit (Cont'd)



DIAGNOSTIC PROCEDURE

SYMPTOM: Sunload sensor circuit is open or shorted. (25 or -25 is indicated on the display as a result of conducting Self-diagnosis STEP 2.)

1	CHECK SUNLOAD SENSOR CIRCUIT BETWEEN SUNLOAD SENSOR AND BODY GROUND										
<p>Disconnect sunload sensor harness connector.</p> <p>Do approx. 5 volts exist between sunload sensor harness terminal No. 1 and body ground?</p>											
<div><div><div>Sunload sensor connector (M85)</div><div></div></div><div><div>OR</div><div></div></div><div><div></div><div></div><div></div></div></div> <div>RHA062GD</div> <tr><td colspan="3">Yes or No</td></tr> <tr><td>Yes</td><td>▶</td><td>GO TO 2.</td></tr> <tr><td>No</td><td>▶</td><td>GO TO 4.</td></tr>			Yes or No			Yes	▶	GO TO 2.	No	▶	GO TO 4.
Yes or No											
Yes	▶	GO TO 2.									
No	▶	GO TO 4.									


2	CHECK SUNLOAD SENSOR CIRCUIT BETWEEN SUNLOAD SENSOR AND AUTO AMP. (LCU)	
<div>1. Disconnect auto amp. (LCU) harness connector.</div> <div>2. Check circuit continuity between sunload sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11.</div> <div>3. Check circuit continuity between sunload sensor harness terminal No. 2 and body ground.</div>		
<div><div><div><div>Auto amp. (LCU) connector (M59)</div></div><div><div>Sunload sensor connector (M85)</div></div><div><div>Sunload sensor connector (M85)</div></div></div><div></div><div></div></div>		
<div>Continuity should exist.</div> <div>If OK, check harness for short.</div>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness or connector.

TROUBLE DIAGNOSES

AUTO


Sunload Sensor Circuit (Cont'd)

3 CHECK SUNLOAD SENSOR	
Refer to HA-104.	
OK or NG	
OK	<p>► 1. Replace auto amp. (LCU).</p> <p>2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2.</p> <p>Confirm that code No. 20 is displayed.</p>
NG	<p>► 1. Replace sunload sensor.</p> <p>2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2.</p> <p>Confirm that code No. 20 is displayed.</p>

4 CHECK SUNLOAD SENSOR CIRCUIT BETWEEN SUNLOAD SENSOR AND AUTO AMP. (LCU)	
<p>1. Disconnect auto amp. (LCU) harness connector.</p> <p>2. Check circuit continuity between sunload sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 12.</p>	
<div style="text-align: center;">  </div>	
<p>Continuity should exist.</p> <p>If OK, check harness for short.</p>	
OK or NG	
OK	<p>► 1. Replace auto amp.</p> <p>2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2.</p> <p>Confirm that code No. 20 is displayed.</p>
NG	<p>► Repair harness or connector.</p>

RHA484GC

Sunload Sensor Circuit (Cont'd)



COMPONENT INSPECTION


Sunload Sensor

Measure voltage between auto amp. terminal 12 and body ground. If NG, replace sunload sensor.


- When checking sunload sensor, select a place where sun shines directly on it.

NFHA0224

NFHA0224S01



SHA930E



Intake Sensor Circuit

COMPONENT DESCRIPTION

Intake Sensor

The intake sensor is located on the cooling unit. It converts temperature of air after it passes through the evaporator into a resistance value which is then input to the auto amp.

After disconnecting intake sensor harness connector, measure resistance between terminals 1 and 2 at sensor harness side, using the table below.

NFHA0225

NFHA0225S01

TROUBLE DIAGNOSES

AUTO


Intake Sensor Circuit (Cont'd)

Temperature °C (°F)	Resistance kΩ
−15 (5)	12.73
−10 (14)	9.92
−5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace intake sensor.

DIAGNOSTIC PROCEDURE

SYMPTOM: Intake sensor circuit is open or shorted. (P04 or P05 is indicated on the display as a result of conducting Self-diagnosis STEP 2.)



1

CHECK INTAKE SENSOR CIRCUIT BETWEEN INTAKE SENSOR AND BODY GROUND

Disconnect intake sensor harness connector.

Do approx. 5 volts exist between intake sensor harness terminal No. 1 and body ground?

DISCONNECT


Intake sensor connector (M80)

RHA417H


Yes or No

Yes	▶	GO TO 2.
No	▶	GO TO 4.

Intake Sensor Circuit (Cont'd)

2 CHECK INTAKE SENSOR CIRCUIT BETWEEN INTAKE SENSOR AND AUTO AMP. (LCU)	
<ol style="list-style-type: none"> 1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between intake sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11. 3. Check circuit continuity between intake sensor harness terminal No. 2 and body ground. 	
 <p style="text-align: right;">RHA566HA</p>	
<p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p>	
OK	GO TO 3.
NG	Repair harness or connector.

3 CHECK INTAKE SENSOR	
Refer to HA-104.	
OK or NG	
OK	<ol style="list-style-type: none"> 1. Replace auto amp. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
NG	<ol style="list-style-type: none"> 1. Replace intake sensor. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.

4 CHECK INTAKE SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND AUTO AMP. (LCU)	
<ol style="list-style-type: none"> 1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between intake sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 1. 	
 <p style="text-align: right;">RHA419H</p>	
<p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p>	
OK	<ol style="list-style-type: none"> 1. Replace auto amp. 2. Go to "FUNCTION CONFIRMATION PROCEDURE", "Self-diagnosis", HA-39 and perform self-diagnosis STEP-2. Confirm that code No. 20 is displayed.
NG	Repair harness or connector.

Air Mix Door Motor PBR Circuit

DIAGNOSTIC PROCEDURE

For description of air mix door motor, mode door motor and intake door motor circuit, refer to HA-63.

NFHA0227

SYMPTOM: If PBR circuit is open or shorted. (-25 or 25 is indicated on the display as a result of conducting Self-diagnosis STEP 2.)

Perform diagnostic procedure for air mix door motor, mode door motor and intake. Refer to HA-58.

HFC-134a (R-134a) Service Procedure

NFHA0228

NFHA0228S01

NFHA0228S0101


SETTING OF SERVICE TOOLS AND EQUIPMENT

Discharging Refrigerant

WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Use only approved recovery/recycling equipment to discharge HFC-134a (R-134a) refrigerant. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.

Example




SHA539DE

Evacuating System and Charging Refrigerant


NFHA0228S0102

Example


Preferred (Best) method



Alternate method



Recovered lubricant. Refer to
"CHECKING AND ADJUSTING",
*1.



SHA383F

*1: HA-110

*3: HA-122

*4: HA-83

*2: HA-121

Maintenance of Lubricant Quantity in Compressor

The lubricant in the compressor circulates through the system with the refrigerant. Add lubricant to compressor when replacing any component or after a large gas leakage occurred. It is important to maintain the specified amount. If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)

LUBRICANT

Name: Nissan A/C System Oil Type S

Part number: KLH00-PAGS0

CHECKING AND ADJUSTING

Adjust the lubricant quantity according to the test group shown below.

1	CHECK LUBRICANT RETURN OPERATION	
Can lubricant return operation be performed? ● A/C system works properly. ● There is no evidence of a large amount of lubricant leakage.		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	PERFORM LUBRICANT RETURN OPERATION, PROCEEDING AS FOLLOWS:	
1. Start engine, and set the following conditions: Test condition Engine speed: Idling to 1,200 rpm A/C or AUTO switch: ON Blower speed: Max. position Temp. control: Optional [Set so that intake air temperature is 25 to 30°C (77 to 86°F).] 2. Next item is for V-6 compressor. Connect the manifold gauge, and check that the high pressure side pressure is 588 kPa (5.9 bar, 6 kg/cm ² , 85 psi) or higher. If less than the reference level, attach a cover to the front face of the condenser to raise the pressure. 3. Perform lubricant return operation for about 10 minutes. 4. Stop engine. CAUTION: If excessive lubricant leakage is noted, do not perform the lubricant return operation.		
OK	▶	GO TO 3.

3	CHECK COMPRESSOR	
Should the compressor be replaced?		
Yes or No		
Yes	▶	Go to "Lubricant Adjustment Procedure for Compressor Replacement", (HA-111).
No	▶	GO TO 4.

4	CHECK ANY PART	
Is there any part to be replaced? (Evaporator, condenser, liquid tank or in case there is evidence of a large amount of lubricant leakage.)		
Yes or No		
Yes	▶	Go to "Lubricant Adjusting Procedure for Components Replacement Except Compressor", (HA-111).
No	▶	Carry out the A/C performance test.

Lubricant Adjusting Procedure for Components Replacement Except Compressor

NFHA0229S0201

After replacing any of the following major components, add the correct amount of lubricant to the system.

Amount of lubricant to be added

Part replaced	Lubricant to be added to system	Remarks
	Amount of lubricant mℓ (Imp fl oz)	
Evaporator	75 (2.6)	—
Condenser	75 (2.6)	—
Liquid tank	5 (0.2)	Add if compressor is not replaced. *1
In case of refrigerant leak	30 (1.1)	Large leak
	—	Small leak *2

*1: If compressor is replaced, addition of lubricant is included in the table.

*2: If refrigerant leak is small, no addition of lubricant is needed.

Lubricant Adjusting Procedure for Compressor Replacement

NFHA0229S0202


1. Discharge refrigerant into the refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
2. Remove the drain plug of the "old" (removed) compressor. Drain the lubricant into a graduated container and record the amount of drained lubricant.
3. Remove the drain plug and drain the lubricant from the "new" compressor into a separate, clean container.
4. Measure an amount of new lubricant installed equal to amount drained from "old" compressor. Add this lubricant to "new" compressor through the suction port opening.
5. Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to "new" compressor through the suction port opening.
6. Torque the drain plug.

18 - 19 N·m (1.8 - 1.9 kg-m, 13 - 14 ft-lb)
7. If the liquid tank also needs to be replaced, add an additional 5 mℓ (0.2 Imp fl oz) of lubricant at this time.
Do not add this 5 mℓ (0.2 Imp fl oz) of lubricant if only replacing the compressor.

SERVICE PROCEDURE

AUTO

Maintenance of Lubricant Quantity in Compressor (Cont'd)




RHA065DI

**Compressor
REMOVAL AND INSTALLATION**

NFHA0230

SEC. 274-275




RHA463E

**Compressor Clutch
OVERHAUL**


NFHA0231

SEC. 274




RHA122F

Compressor Clutch (Cont'd)




REMOVAL


- When removing center bolt, hold clutch disc with clutch disc wrench. NFHA0232




- Remove the clutch disc using the clutch disc puller. Insert the holder's three pins into the holes in the clutch disc. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the clutch disc. After removing the clutch disc, remove the shims from either the drive shaft or the clutch disc.




- Remove the snap ring using external snap ring pliers.




- Pulley removal**
Position the center pulley puller on the end of the drive shaft, and remove the pulley assembly using any commercially available pulley puller. **To prevent the pulley groove from being deformed, the puller claws should be positioned onto the edge of the pulley assembly.**






- Remove the field coil harness clip using a pair of pliers.



- Remove the snap ring using external snap ring pliers.



INSPECTION

NFHA0233

Clutch Disc

NFHA0233S01

If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

Pulley


NFHA0233S02

Check the appearance of the pulley assembly. If the contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

NFHA0233S03

Check coil for loose connection or cracked insulation.




INSTALLATION


NFHA0234

- Install the field coil.
Be sure to align the coil's pin with the hole in the compressor's front head.
- Install the field coil harness clip using a screwdriver.


Compressor Clutch (Cont'd)




- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



- Install the clutch disc on the drive shaft, together with the original shim(s). Press the clutch disc down by hand.



- Using the holder to prevent clutch disc rotation, tighten the bolt to 14 N·m (1.4 kg-m, 10 ft-lb) torque.
After tightening the bolt, check that the pulley rotates smoothly.



- Check clearance around the entire periphery of clutch disc.
Disc-to-pulley clearance:
0.3 - 0.6 mm (0.012 - 0.024 in)
If the specified clearance is not obtained, replace adjusting spacer and readjust.

Break-in Operation


NFHA0234S01

When replacing compressor clutch assembly, always carry out the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.

Heater Unit (Heater Core) REMOVAL

NFHA0249

This illustration is for LHD models.
The layout for RHD models is symmetrically opposite.



RHA567H

1. Drain the cooling system. Refer to **MA-16**, "Changing Engine Coolant".
2. Discharge the A/C system. Refer to HA-108.
3. Disconnect the two heater hoses from inside the engine compartment.
4. Remove the Blower and cooling unit. Refer to HA-118.
5. Remove the steering member assembly. Refer to **BT-20**, "Removal and Installation".
6. Remove the heater unit.
7. Remove the heater core.

INSTALLATION

NFHA0250



Installation is basically the reverse order of removal.

When filling radiator with coolant, refer to MA-16, "Changing Engine Coolant".

Recharge the A/C system. Refer to HA-108.

Blower and Cooling Unit (A/C Evaporator) REMOVAL

NFHA0251



1. Discharge the A/C system. Refer to HA-108.
2. Disconnect the two refrigerant lines from the engine compartment.
Cap the A/C lines to prevent moisture from entering the system.
3. Remove the glove box and mating trim. Refer to **BT-20**, "Removal and Installation - Instrument Panel Assembly".
4. Disconnect the thermal amp. connector.
5. Disconnect the intake sensor connector.
6. Disconnect the fan control amp. and blower motor connector.
7. Remove the blower and cooling unit.
8. Separate the blower and cooling unit case, and remove the evaporator.
9. Remove the three bolts and then remove the motor from the blower case.

INSTALLATION

Installation is basically the reverse order of removal.

Recharge the A/C system. Refer to HA-108.

NFHA0252


Refrigerant Lines

REMOVAL AND INSTALLATION

=NFHA0235

- Refer to page HA-4 regarding "Precautions for Refrigerant Connection".


LHD models



- : Refrigerant leak checking points
- : (Tightening torque)
- □ : (Wrench size)
- : (O-ring size)
- ⊗ : N·m (kg-m, in-lb)
- ⊙ : N·m (kg-m, ft-lb)
- A** : 2.9 - 5.9 (0.29 - 0.61, 26 - 52)
- B** : 7.8 - 19.6 (0.78 - 2.00, 68 - 173)
- C** : 15 - 24 (1.5 - 2.4, 11 - 18)

RHA423HB

RHD models



- : Refrigerant leak checking points
- : (Tightening torque)
- □ : (Wrench size)
- : (O-ring size)
- ⊗ : N•m (kg-m, in-lb)
- Ⓐ : 2.9 - 5.9 (0.29 - 0.61, 26 - 52)
- Ⓑ : 7.8 - 19.6 (0.78 - 2.00, 68 - 173)
- Ⓢ : N•m (kg-m, ft-lb)
- Ⓒ : 15 - 24 (1.5 - 2.4, 11 - 18)

RHA900H

- Refer to page HA-4 regarding "Precautions for Refrigerant Connection".


CHECKING REFRIGERANT LEAKS

NFHA0236

Preliminary Check

=NFHA0236S01

Perform a visual inspection of all refrigeration parts, fittings, hoses, and components for signs of A/C lubricant leakage, damage and corrosion. Take note of the areas with A/C lubricant leakage to allow extra time in these areas with electronic leak detector.




Precautions for Handling Leak Detector

NFHA0236S02


When performing a refrigerant leak check, use an A/C leak detector or equivalent. Ensure that the instrument is calibrated and set properly per the operating instructions.

The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.

Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and lubricants, may falsely trigger the leak detector. Make sure the surfaces to be checked are clean. Clean with a dry cloth or blow off with shop air. Do not allow the sensor tip of the detector to contact with any substance. This can also cause false readings and may damage the detector.




1. Position probe approximately 5 mm (3/16 in) away from point to be checked.



2. When testing, circle each fitting completely with probe.

Refrigerant Lines (Cont'd)



3. Move probe along component approximately 25 to 50 mm (1 to 2 in)/sec.

Checking Procedure

NFHA0236S03

To prevent inaccurate or false readings, make sure there is no refrigerant vapor, shop chemicals, or cigarette smoke in the vicinity of the vehicle. Perform the leak test in calm area (low air/wind movement) so that the leaking refrigerant is not dispersed.

1. Turn engine off.
2. Connect a suitable A/C manifold gauge set to the A/C service ports.
3. Check if the A/C refrigerant pressure is at least 345 kPa (3.45 bar, 3.52 kg/cm², 50 psi) above 16°C (61°F). If less than specification, recover/evacuate and recharge the system with the specified amount of refrigerant.

NOTE:

At temperatures below 16°C (61°F), leaks may not be detected since the system may not reach 345 kPa (3.45 bar, 3.52 kg/cm², 50 psi).

4. Conduct the leak test from the high side (compressor discharge **a** to evaporator inlet **e**) to the low side (evaporator discharge **e** to shaft seal **j**). Refer to HA-119. Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detector probe completely around the connection/component.


- **Compressor**
Check the fitting of high and low pressure hoses, relief valve and shaft seal.
- **Liquid tank**
Check the refrigerant pressure sensor, tube fitting, weld seams and the fusible plug mount.
- **Service valves**
Check all around the service valves. Ensure service valve caps are secured on the service valves (to prevent leaks).

NOTE:

After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any false readings by leak detector.

- **Cooling unit (Evaporator)**
With engine OFF, turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Wait a minimum of 10 minutes accumulation time (refer to the manufacturer's recommended procedure for actual wait time) before inserting the leak detector probe into the drain hose. Keep the probe inserted for at least ten seconds. Use caution not to contaminate the probe tip with water or dirt that may be in the drain hose.

5. If a leak detector detects a leak, verify at least once by blowing compressed air into area of suspected leak, then repeat check as outlined above.
6. Do not stop when one leak is found. Continue to check for additional leaks at all system components. If no leaks are found, perform steps 7 - 10.
7. Start engine.
8. Set the heater A/C control as follows:
 - 1) A/C or AUTO switch ON.
 - 2) Face mode
 - 3) Recirculation switch ON
 - 4) Max cold temperature
 - 5) Fan speed high
9. Run engine at 1,500 rpm for at least 2 minutes.
10. Turn engine off and perform leak check again following steps 4 through 6 above.



Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector at the compressor. The pressure on the high pressure side will gradually drop after refrigerant circulation stops and pressure on the low pressure side will gradually rise, as shown in the graph. Some leaks are more easily detected when pressure is high.

11. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component as necessary.
12. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
13. Conduct A/C performance test to ensure system works properly.

Belt

TENSION ADJUSTMENT

- Refer to MA-15, "Checking Drive Belt".


NFHA0237

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve

INSPECTION

- Refer to EC-339, and HA-18, "Description".

NFHA0238



Ventilation Air Filter


FUNCTION

Air inside passenger compartment is kept clean at either recirculation or fresh mode by installing ventilation air filter into cooling unit. NFHA0266

NOTE:

To replace ventilation air filter, refer to "PERIODIC MAINTENANCE", MA-7.

Caution label is fixed inside the glove box.



REPLACEMENT PROCEDURE

NFHA0267

- Remove glove box.
- Remove instrument lower panel from instrument panel.
- Remove filter cover fixed clip.
- Slide the filter cover to the upper side and then remove it.
- Take out the lower side ventilation air filter from cooling unit.
- Then slide upper side filter to the bottom position and take off the ventilation air filter from the cooling unit.
- Replace with new one and reinstall on cooling unit.
- Reinstall filter cover, clip, instrument lower panel and glove box.

Auto

COMPRESSOR

NFHA0241

Model		CALSONIC make V-6
Type		V-6 variable displacement
Displacement cm ³ (cu in)/rev.	Max.	184 (11.228)
	Min.	14.5 (0.885)
Cylinder bore x stroke mm (in)		37 (1.46) x [2.3 - 28.6 (0.091 - 1.126)]
Direction of rotation		Clockwise (viewed from drive end)
Drive belt		Poly V

LUBRICANT

NFHA0242

Model		CALSONIC make V-6
Name		Nissan A/C System Oil Type S
Part number*		KLH00-PAGS0
Capacity mℓ (Imp fl oz)	Total in system	200 (7.0)
	Compressor (Service part) charging amount	200 (7.0)

*: Always check with the Parts Department for the latest parts information.

REFRIGERANT

NFHA0243

Type	HFC-134a (R-134a)
Capacity kg (lb)	0.60 - 0.70 (1.32 - 1.54)

ENGINE IDLING SPEED (WHEN A/C IS ON)

NFHA0244

- Refer to *EC*, “Description”.

BELT TENSION

NFHA0245

- Refer to *MA-15*, “Checking Drive Belts”.

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NFHA0060

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL A33 is as follows (The composition varies according to optional equipment.):

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation or tape either just before the harness connectors or for the complete harness are related to the SRS.

Precautions for Working with HFC-134a (R-134a)

NFHA0061

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. These refrigerants must never be mixed, even in the smallest amounts. If the refrigerants are mixed and compressor failure is likely to occur.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubricant other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - a) When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b) When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - c) Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - d) Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Use only approved recovery/recycling equipment to discharge HFC-134a (R-134a) refrigerant. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e) Do not allow lubricant (Nissan A/C System Oil Type S) to come in contact with styrofoam parts. Damage may result.

General Refrigerant Precautions

=NFHA0062

WARNING:

- Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.
- Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
- Do not store or heat refrigerant containers above 52°C (125°F).
- Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.
- Do not intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.
- Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Do not pressure test or leak test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and R-134a have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.

Precautions for Refrigerant Connection

NFHA0063


A new type refrigerant connection has been introduced to all refrigerant lines except the following portion.

- Expansion valve to cooling unit

FEATURES OF NEW TYPE REFRIGERANT CONNECTION

NFHA0063S01


- The O-ring has been relocated. It has also been provided with a groove for proper installation. This eliminates the chance of the O-ring being caught in, or damaged by, the mating part. The sealing direction of the O-ring is now set vertically in relation to the contacting surface of the mating part to improve sealing characteristics.
- The reaction force of the O-ring will not occur in the direction that causes the joint to pull out, thereby facilitating piping connections.



O-RING AND REFRIGERANT CONNECTION

NFHA0063S02

This illustration is for LHD models.
The layout for RHD models is symmetrically opposite.




RHA452HA

CAUTION:

The new and former refrigerant connections use different O-ring configurations. Do not confuse O-rings since they are not interchangeable. If a wrong O-ring is installed, refrigerant will leak at, or around, the connection.

O-Ring Part Numbers and Specifications

NFHA0063S0201

	Connection type	O-ring size	Part number	D mm (in)	W mm (in)
	New	8	92471 N8210	6.8 (0.268)	1.85 (0.0728)
	Former		92470 N8200	6.07 (0.2390)	1.78 (0.0701)
	New	12	92472 N8210	10.9 (0.429)	2.43 (0.0957)
	Former		92475 71L00	11.0 (0.433)	2.40 (0.0945)
	New	16	92473 N8210	13.6 (0.535)	2.43 (0.0957)
	Former		92475 72L00	14.3 (0.563)	2.30 (0.0906)
	New	19	92474 N8210	16.5 (0.650)	2.43 (0.0957)
	Former		92477 N8200	17.12 (0.6740)	1.78 (0.0701)

WARNING:


Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:

When replacing or cleaning refrigerant cycle components, observe the following.

- When the compressor is removed, store it in the same position as it is when mounted on the car. Failure to do so will cause lubricant to enter the low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, immediately plug all openings to prevent entry of dirt and moisture.
- When installing an air conditioner in the vehicle, connect the pipes as the final stage of the operation. Do not remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to circle of the O-rings shown in illustration. Be careful not to apply lubricant to threaded portion.
Lubricant name: Nissan A/C System Oil Type S
Part number: KLH00-PAGS0
- O-ring must be closely attached to dented portion of tube.
- When replacing the O-ring, be careful not to damage O-ring and tube.
- Connect tube until you hear it click, then tighten the nut or bolt by hand until snug. Make sure that the O-ring is installed to tube correctly.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.

Precautions for Servicing Compressor



Precautions for Servicing Compressor

NFHA0064

- Plug all openings to prevent moisture and foreign matter from entering.
- When the compressor is removed, store it in the same position as it is when mounted on the car.
- When replacing or repairing compressor, follow “Maintenance of Lubricant Quantity in Compressor” exactly. Refer to HA-195.
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated, with lubricant, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour.
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation.

Precautions for Service Equipment

NFHA0065

RECOVERY/RECYCLING EQUIPMENT


NFHA0065S01

Follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

NFHA0065S02

Follow the manufacture's instructions for tester operation and tester maintenance.



VACUUM PUMP

NFHA0065S03

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched off after evacuation (vacuuming) and hose is connected to it.

To prevent this migration, use a manual valve situated near the hose-to-pump connection, as follows.


- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut off valve, disconnect the hose from the pump: as long as the hose is connected, the valve is open and lubricating oil may migrate.

Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.

MANIFOLD GAUGE SET

NFHA0065S04


Be certain that the gauge face indicates R-134a or 134a. Make sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) along with specified lubricant.



SERVICE HOSES

NFHA0065S05


Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must include positive shut off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.




SERVICE COUPLERS

NFHA0065S06

Never attempt to connect HFC-134a (R-134a) service couplers to an CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.



Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close



REFRIGERANT WEIGHT SCALE

NFHA0065S07

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. If the scale controls refrigerant flow electronically, the hose fitting must be 1/2"-16 ACME.

CALIBRATING ACR4 WEIGHT SCALE

NFHA0065S09

Calibrate the scale every three months.

To calibrate the weight scale on the ACR4:

1. Press **Shift/Reset** and **Enter** at the same time.
2. Press **8787**. "A1" will be displayed.
3. Remove all weight from the scale.
4. Press **0**, then press **Enter**. "0.00" will be displayed and change to "A2".
5. Place a known weight (dumbbell or similar weight), between 4.5 and 8.6 kg (10 and 19 lb) on the center of the weight scale.
6. Enter the known weight using four digits. (Example 10 lb = 10.00, 10.5 lb = 10.50)
7. Press **Enter** — the display returns to the vacuum mode.
8. Press **Shift/Reset** and **Enter** at the same time.
9. Press **6** — the known weight on the scale is displayed.
10. Remove the known weight from the scale. "0.00" will be displayed.
11. Press **Shift/Reset** to return the ACR4 to the program mode.

CHARGING CYLINDER

NFHA0065S08

Using a charging cylinder is not recommended. Refrigerant may be vented into air from cylinder's top valve when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

Wiring Diagrams and Trouble Diagnoses

NFHA0066

When you read wiring diagrams, refer to the following:






- **GI-11**, "HOW TO READ WIRING DIAGRAMS"
- **EL-9**, "Wiring Diagram — POWER —" for power distribution circuit

When you perform trouble diagnoses, refer to the following:

- **GI-33**, "HOW TO FOLLOW TROUBLE DIAGNOSES"
- **GI-22**, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

Special Service Tools

NFHA0067

Tool number Tool name	Description
KV99106100 Clutch disc wrench	<p>Removing center bolt</p>  <p>NT232</p>  <p>When replacing the magnet clutch in the above compressor, use a clutch disc wrench with the pin side on the clutch disc to remove it.</p>  <p>NT378</p>
KV99232340 or KV992T0001 Clutch disc puller	<p>Removing clutch disc</p>  <p>NT376</p>
KV99106200 Pulley installer	<p>Installing pulley</p>  <p>NT235</p>

HFC-134a (R-134a) Service Tools and Equipment






=NFHA0068

Never mix HFC-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.

Separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubricant.

Refrigerant container fittings, service hose fittings and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and HFC-134a (R-134a). This is to avoid mixed use of the refrigerants/lubricant.





Adapters that convert one size fitting to another must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.

Tool number Tool name	Description
HFC-134a (R-134a) refrigerant	 <p>Container color: Light blue Container marking: HFC-134a (R-134a) Fitting size: Thread size</p> <ul style="list-style-type: none"> Large container 1/2"-16 ACME
KLH00-PAGS0 Nissan A/C System Oil Type S	 <p>Type: Poly alkylene glycol oil (PAG), type S Application: HFC-134a (R-134a) swash plate (piston) compressors (Nissan only) Lubricity: 40 ml (1.4 Imp fl oz)</p>
Recovery/Recycling Recharging equipment (ACR4)	 <p>Function: Refrigerant Recovery and Recycling and Recharging</p>
Electrical leak detector	 <p>Power supply:</p> <ul style="list-style-type: none"> DC 12V (Cigarette lighter)
Manifold gauge set (with hoses and couplers)	 <p>Identification:</p> <ul style="list-style-type: none"> The gauge face indicates R-134a. <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> 1/2"-16 ACME

PREPARATION

MANUAL

HFC-134a (R-134a) Service Tools and Equipment (Cont'd)

Tool number Tool name	Description
Service hoses <ul style="list-style-type: none"> • High side hose • Low side hose • Utility hose 	<div>  </div> <p>NT201</p> <div> <p>Hose color:</p> <ul style="list-style-type: none"> • Low hose: Blue with black stripe • High hose: Red with black stripe • Utility hose: Yellow with black stripe or green with black stripe <p>Hose fitting to gauge:</p> <ul style="list-style-type: none"> • 1/2"-16 ACME </div>
Service couplers <ul style="list-style-type: none"> • High side coupler • Low side coupler 	<div>  </div> <p>NT202</p> <div> <p>Hose fitting to service hose:</p> <ul style="list-style-type: none"> • M14 x 1.5 fitting is optional or permanently attached. </div>
Refrigerant weight scale	<div>  </div> <p>NT200</p> <div> <p>For measuring of refrigerant</p> <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> • 1/2"-16 ACME </div>
Vacuum pump (Including the isolator valve)	<div>  </div> <p>NT203</p> <div> <p>Capacity:</p> <ul style="list-style-type: none"> • Air displacement: 4 CFM • Micron rating: 20 microns • Oil capacity: 482 g (17 oz) <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> • 1/2"-16 ACME </div>

Refrigeration System

REFRIGERATION CYCLE

Refrigerant Flow

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the liquid tank, through the evaporator, and back to the compressor. The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.

NFHA0069

NFHA0069S01

Freeze Protection

Under normal operating conditions, when the A/C is switched on, the compressor runs continuously, and the evaporator pressure, and therefore, temperature is controlled by the V-6 variable displacement compressor to prevent freeze up.

NFHA0069S02

Refrigerant System Protection

Refrigerant Pressure Sensor

The refrigerant system is protected against excessively high or low pressures by the refrigerant pressure sensor, located on the liquid tank. If the system pressure rises above, or falls below the specifications, the refrigerant pressure sensor detects the pressure inside the refrigerant line and sends the voltage signal to the ECM. ECM makes the A/C relay go OFF and stops the compressor when pressure on the high pressure side detected by refrigerant pressure sensor is over about 2,746 kPa (27.5 bar, 28 kg/cm², 398 psi) or below about 137 kPa (1.37 bar, 1.4 kg/cm², 20 psi).


NFHA0069S03

NFHA0069S0301

Pressure Relief Valve

The refrigerant system is also protected by a pressure relief valve, located in the rear head of the compressor. When the pressure of refrigerant in the system increases to an abnormal level [more than 3,727 kPa (37.3 bar, 38 kg/cm², 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere.

NFHA0069S0302



RHA347H

V-6 Variable Displacement Compressor**GENERAL INFORMATION**

=NFHA0070

1. The V-6 variable compressor differs from previous units. The vent temperatures of the V-6 variable compressor do not drop too far below 5°C (41°F) when:
 - evaporator intake air temperature is less than 20°C (68°F)
 - engine is running at speeds less than 1,500 rpm.This is because the V-6 compressor provides a means of “capacity” control.
2. The V-6 variable compressor provides refrigerant control under varying conditions. During cold winters, it may not produce high refrigerant pressure discharge (compared to previous units) when used with air conditioning systems.
3. A “clanking” sound may occasionally be heard during refrigerant charge. The sound indicates that the tilt angle of the swash plate has changed and is not a problem.
4. For air conditioning systems with the V-6 compressor, the clutch remains engaged unless: the system main switch, fan switch or ignition switch is turned OFF. When ambient (outside) temperatures are low or when the amount of refrigerant is insufficient, the clutch is disengaged to protect the compressor.
5. A constant range of suction pressure is maintained when engine speed is greater than a certain value. It normally ranges from 147 to 177 kPa (1.47 to 1.77 bar, 1.5 to 1.8 kg/cm², 21 to 26 psi) under varying conditions.

In previous compressors, however, suction pressure was reduced with increases in engine speed.

DESCRIPTION


General

=NFHA0132

NFHA0132S01

The variable compressor is basically a swash plate type that changes piston stroke in response to the required cooling capacity.

The tilt of the swash plate allows the piston's stroke to change so that refrigerant discharge can be continuously changed from 14.5 to 184 cm³ (0.885 to 11.228 cu in).



Discharge control	Discharge capacity cm ³ (cu in)/rev.	Piston stroke length mm (in)
Minimum	14.5 (0.885)	2.3 (0.091)
Maximum	184 (11.228)	28.6 (1.126)

RHA037DB

Operation

1. Operation Control Valve

=NFHA0132S02

NFHA0132S0201

Operation control valve is located in the suction port (low-pressure) side, and opens or closes in response to changes in refrigerant suction pressure.

Operation of the valve controls the internal pressure of the crankcase.

The angle of the swash plate is controlled between the crankcase's internal pressure and the piston cylinder pressure.

2. Maximum Cooling

NFHA0132S0202


Refrigerant pressure on the low-pressure side increases with an increase in heat loads.

When this occurs, the control valve's bellows compress to open the low-pressure side valve and close the high-pressure side valve.

This causes the following pressure changes:

- the crankcase's internal pressure to equal the pressure on the low-pressure side;
- the cylinder's internal pressure to be greater than the crankcase's internal pressure.


Under this condition, the swash plate is set to the maximum stroke position.



3. Capacity Control

=NFHA0132S0203

- Refrigerant pressure on suction side is low during high speed driving or when ambient or interior temperature is low.
- The bellows expands when refrigerant pressure on the suction pressure side drops below approximately 177 kPa (1.77 bar, 1.8 kg/cm², 26 psi). Since suction pressure is low, it makes the suction port close and the discharge port open. Thus, crankcase pressure becomes high as high pressure enters the crankcase.
- The force acts around the journal pin near the swash plate, and is generated by the pressure difference before and behind the piston.
The drive lug and journal pin are located where the piston generates the highest pressure. Piston pressure is between suction pressure P_s and discharge pressure P_d , which is near suction pressure P_s . If crankcase pressure P_c rises due to capacity control, the force around the journal pin makes the swash plate angle decrease and also the piston stroke decrease. In other words, crankcase pressure increase triggers pressure difference between the piston and the crankcase. The pressure difference changes the angle of the swash plate.



RHA474C

IACV-AAC CONTROL SYSTEM

=NFHA0133

Operation


NFHA0133S02

When the air conditioner is OFF, the ECM detects the load applied to the engine, and controls the IACV-AAC valve to adjust the engine idling speed to the appropriate rpm by supplying additional air from the IACV-AAC valve.

When the air conditioner is ON (A/C relay is ON), refrigerant-pressure sensor converts refrigeration-pressure on the high pressure side into the voltage value, which is output to ECM which protects refrigeration cycle and control idle speed by the output voltage data, and additional air is supplied to the engine. If the appropriate engine speed is not reached, the IACV-AAC valve supplies the additional air required to increase the engine rpm.

Component Layout


NFHA0071



RHA349HA

Control Operation

NFHA0072



SHA337F

FAN CONTROL DIAL

This dial turns the fan ON and OFF, and controls fan speed.

NFHA0072S01

MODE SWITCHES

This switch allows control of the outlet air flow.

NFHA0072S02

In "DEF" or "D/F" mode, the intake door is set to "FRESH".

The compressor turns on when the Mode switch is moved to "DEF".

TEMPERATURE CONTROL LEVER

This lever allows adjustment of the temperature of the outlet air.

NFHA0072S03

RECIRCULATION (REC) SWITCH

OFF position: Outside air is drawn into the passenger compartment.

NFHA0072S04

ON position: Interior air is recirculated inside the vehicle. The indicator lamp will also light.

Recirculation is canceled when DEF or D/F is selected, and resumes when another mode is chosen.

If the refrigerant pressure sensor input signal is high, recirculation is canceled, when VENT, B/L and FOOT mode is selected.

AIR CONDITIONER SWITCH

The air conditioner switch controls the A/C system. When the switch is depressed with the fan ON, the compressor will turn ON. The indicator lamp will also light.

NFHA0072S05

The air conditioner cooling function operates only when the engine is running.

REAR WINDOW DEFOGGER SWITCH


When illumination is ON, rear window is defogging.

NFHA0072S06


Discharge Air Flow

NFHA0073


① : Face ② : Foot ③ : Defroster




Floor




Face
(switch "ON")




Floor and defroster



Bi-level
(switch "OFF")



Defroster



★ : LHD models for Europe.

This illustration is for LHD models.

The layout for RHD models is symmetrically opposite.


SHA424FA

System Description

SWITCHES AND THEIR CONTROL FUNCTIONS

NFHA0074

NFHA0074S01



SHA378F

Position or switch	MODE SW				Front DEF SW		A/C SW	Intake SW			Temperature lever		
	VENT	B/L	FOOT	D/F	ON	OFF		REC SW *1	FRE SW				
Door							A/C				18.0°C (65°F)	—	32.0°C (85°F)
Ventilator door	A	B	*2	*2	*2	—	—				—		
Foot door	C	B	A	B	C						—		
Defroster door	D	D	C	B	A						—		
Air mix door	—				—						B	→	A
Intake door	—				A			B	AUTO	A	—		

*1: In DEF and D/F models, REC switch is canceled.

*2: Except LHD models for Europe: C

LHD models for Europe: B


SHA443F

Component Location

ENGINE COMPARTMENT

NFHA0085


NFHA0085S01



RHA455H

PASSENGER COMPARTMENT


NFHA0085S02



RHA456HA

Circuit Diagram — Air Conditioner

NFHA0087









MHA936A

Wiring Diagram — A/C, Heater —




NFHA0265

HA-HEATER-01




HA-A/C,M-01

L : LHD MODELS
R : RHD MODELS



REFER TO THE FOLLOWING.
 (M19) - FUSE BLOCK - JUNCTION BOX (J/B)

HA-A/C,M-02



4	O	5
1	2	3

(M50)
B

		30	17		24
		16	26	23	

(M56)
GY

22	20	15	13	10	8	6	4	2
21	11	14	12	9	7	5	3	1


(M57)
GY

7	6	O
5	4	1

(M83)
W

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C,M-03



3 4 2 1 (M37)
BR

6 1 2 (M58)
5 4 3 W

3 5 1 (E93)
4 2 6 W


1 (E102)
2 W

1 2 (E103)
5 7 3 6 BR


1 (L) 1 (R) (E105)
2 G 2 W

MHA939A

HA-A/C,M-04



- (L) : LHD MODELS
 (R) : RHD MODELS
- *1 4: (L)
 5: (R)
 *2 8: (L)
 10: (R)
 *3 6D: (L)
 7D: (R)
 *4 5: (L)
 7: (R)




REFER TO THE FOLLOWING.
 (M15) - SUPER
 MULTIPLE JUNCTION (SMJ)
 (F48) - ELECTRICAL UNITS

How to Perform Trouble Diagnoses for Quick and Accurate Repair

NFHA0075

NFHA0075S01

WORK FLOW



SHA900E

*1: HA-155

SYMPTOM TABLE

NFHA0075S02

Symptom	Reference page	
● A/C system does not come on.	● Go to Trouble Diagnosis Procedure for A/C system.	HA-157
● Mode door does not change.	● Go to Trouble Diagnosis Procedure for Mode door.	HA-160
● Air mix door motor does not operate normally.	● Go to Trouble Diagnosis Procedure for Air mix door motor.	HA-163
● Intake door does not change in VENT, B/L or FOOT mode.	● Go to Trouble Diagnosis Procedure for Intake Door.	HA-167
● Blower motor does not rotate at all.	● Go to Trouble Diagnosis Procedure for Blower Motor.	HA-170
● Magnet clutch does not engage when A/C switch and fan switch are ON.	● Go to Trouble Diagnosis Procedure for Magnet Clutch.	HA-176
● Insufficient cooling.	● Go to Trouble Diagnosis Procedure for Insufficient cooling.	HA-183
● Insufficient heating.	● Go to Trouble Diagnosis Procedure for Insufficient heating.	HA-191
● Noise	● Go to Trouble Diagnosis Procedure for Noise.	HA-192

Operational Check

=NFHA0076

The purpose of the operational check is to confirm that the system operates as it should. The systems which are checked are the blower, mode (discharge air), intake air, temperature decrease, temperature increase.

CONDITIONS:

Engine running at normal operating temperature.

NFHA0076S01

PROCEDURE:

NFHA0076S02

1. Check Blower

NFHA0076S0201

- Turn fan control dial to 1-speed.
Blower should operate on 1-speed.
- Then turn fan control dial to 2-speed.
- Continue checking blower speed until all four speeds are checked.
- Leave blower on 4-speed.

If NG, go to trouble diagnosis procedure for blower motor (HA-170).
If OK, continue with next check.

2. Check Discharge Air

NFHA0076S0202

- Press each mode switch.

- Confirm that discharge air comes out according to the air distribution table at left.

Refer to "Discharge Air Flow" in "DESCRIPTION" (HA-144).

NOTE:


Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF () is pressed.

Confirm that the intake door position is at FRESH when the D/F () is pressed.


Intake door position is checked in the next step.

If NG, go to trouble diagnosis procedure for mode door motor (HA-160).

If OK, continue with next check.



RHA424H




RHA425H

Discharge air flow

Mode switch	Air outlet/distribution		
	Face	Foot	Defroster
	100%	—	—
	60%	40%	—
	— (20%)	80% (63%)	20% (17%)
	— (20%)	60% (45%)	40% (35%)
	— (20%)	—	100% (80%)

(): LHD models for Europe

SHA345FB



3. Check Recirculation

NFHA0076S0203

1. Press recirculation switch.
Recirculation indicator should light.
2. Listen for intake door position change (you should hear blower sound change slightly).

NOTE:

Confirm that the RECIRCULATION (REC) switch is canceled in the DEF (❄️) and D/F (❄️) mode.

If NG, go to trouble diagnosis procedure for intake door motor (HA-167).

If OK, continue with next check.


4. Check Temperature Decrease

NFHA0076S0204

1. Slide temperature control lever to full cold.
2. Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient cooling motor (HA-183).

If OK, continue with next check.




5. Check Temperature Increase

NFHA0076S0205

1. Slide temperature control lever to full hot.
2. Check for hot air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient heating motor (HA-191).

If OK, continue with next check.



6. Check Air Conditioner Switch

NFHA0076S0206


Turn fan control switch to the desired (1 to 4-speed) position and push the air conditioner switch to turn ON the air conditioner.

The indicator light should come on when air conditioner is ON.

If NG, go to trouble diagnosis procedure for A/C system (HA-157).

If OK, continue with next check.

If all operational check are OK (symptom can not be duplicated), go to "Incident Simulation Tests" (**GI-23**) and perform tests as outlined to simulate driving conditions environment. If symptom appears, refer to "Symptom Table" (HA-154) and perform applicable trouble diagnosis procedures.




A/C System

TROUBLE DIAGNOSIS PROCEDURE FOR A/C SYSTEM

=NFHA0253

Symptom:

- A/C system does not come on.

INSPECTION FLOW

RHA569H

*1: HA-158

*2: HA-155

*3: HA-148

MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

=NFHA0254

Power Supply Circuit Check

NFHA0254S01


Check power supply circuit for air conditioner system.
Refer to *EL-10*, "Wiring Diagram — POWER —".


DIAGNOSTIC PROCEDURE

NFHA0255

SYMPTOM:

- A/C system does not come on.

1	CHECK POWER SUPPLY CIRCUIT FOR A/C CONTROL UNIT									
Measure voltage across terminal No. 14 and body ground.										
<div><div><div>A/C control unit connector (M57)</div><div></div></div><table><tr><th colspan="2">Votmeter terminal</th><th rowspan="2">Voltage</th></tr><tr><th>(+)</th><th>(-)</th></tr><tr><td>14</td><td>Body ground</td><td>Approx. 12V</td></tr></table></div>			Votmeter terminal		Voltage	(+)	(-)	14	Body ground	Approx. 12V
Votmeter terminal		Voltage								
(+)	(-)									
14	Body ground	Approx. 12V								
OK or NG										
OK	▶	GO TO 2.								
NG	▶	Check 10A fuse (No. 19) at fuse block.								

2	CHECK BODY GROUND CIRCUIT FOR A/C CONTROL UNIT									
Check for continuity between terminal No. 17 and body ground.										
<div><div><div>A/C control unit connector (M56)</div><div></div></div></div>										
<table><tr><th colspan="2">Ohmmeter terminal</th><th rowspan="2">Continuity</th></tr><tr><th>(+)</th><th>(-)</th></tr><tr><td>17</td><td>Body ground</td><td>Yes</td></tr></table>		Ohmmeter terminal		Continuity	(+)	(-)	17	Body ground	Yes	RHA391H
Ohmmeter terminal		Continuity								
(+)	(-)									
17	Body ground	Yes								
OK or NG		MTBL0324								
OK	▶	INSPECTION END								
NG	▶	If NG, repair harness or connector.								

Mode Door

TROUBLE DIAGNOSIS PROCEDURE FOR MODE DOOR


=NFHA0142

Symptom:

- Air outlet does not change.

Inspection Flow

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Discharge air.

1) Push mode switch.

2) Confirm that discharge air comes out according to the air distribution table at left.
Refer to "Discharge Air Flow" in "DESCRIPTION" (*4).

Discharge air flow

Mode switch	Mode door/distribution		
	Face	Foot	Defroster
	100%	–	–
	60%	40%	–
	– (20%)	80% (63%)	20% (17%)
	– (20%)	60% (45%)	40% (35%)
	– (20%)	–	100% (80%)

(): LHD models for Europe

2. Check for any service bulletins.

3. Check mode door operation. (*1)

NG

Go to Trouble Diagnosis Procedure for mode door motor. (*5)

OK

INSPECTION END

If the symptom still exist, perform a complete operational check (*2) and check for other symptoms.
[Refer to symptom table, (*3).]
Does another symptom exist?

Yes

Go to Trouble Diagnosis for related symptom.

[Another symptom exists.]

RHA445HB

*1: HA-162

*3: HA-154

*5: HA-161

*2: HA-155

*4: HA-144

DIAGNOSTIC PROCEDURE

SYMPTOM:




- Mode door motor does not operate normally.

1	CHECK POWER SUPPLY FOR A/C CONTROL UNIT	
Refer to “MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK”, HA-158.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair or replace.


2

CHECK FOR OUTPUT OF A/C CONTROL UNIT

Do approx. 10.5 volts exist between mode door motor harness terminal Nos. 8, 9 and body ground?

Mode door motor connector (M48)









Mode door operation	Terminal No.		Voltage
	(+)	(-)	
VENT → DEF	9	Body ground	Approx. 10.5V
DEF → VENT	8		

Yes or No

Yes	▶	GO TO 4.
No	▶	GO TO 3.

SHA328F

SHA328F

3	CHECK CIRCUIT CONTINUITY BETWEEN MODE DOOR MOTOR AND A/C CONTROL UNIT	
Check circuit continuity between mode door motor harness terminal Nos. 8, (9) and A/C control unit harness terminal Nos. 7, (8).		
<div><div></div><div>Mode door motor connector (M48)</div><div></div></div> <div><div>A/C control unit connector (M57)</div><div></div></div> <div></div>		
<div>Continuity should exist.</div> <div>If OK, check harness for short.</div>		
OK or NG		
OK	▶	Replace A/C control unit.
NG	▶	Repair harness or connector.

RHA574H

4

CHECK CIRCUIT CONTINUITY BETWEEN MODE DOOR MOTOR AND A/C CONTROL UNIT

Check circuit continuity between mode door motor harness terminal and A/C control unit harness terminal.


Continuity should exist.

If OK, check harness for short.

OK or NG

OK	▶	Replace air mix door motor.
NG	▶	Repair harness or connector.

RHA395HB



CONTROL LINKAGE ADJUSTMENT

Mode Door

NFHA0151

NFHA0151S01

1. Install mode door motor on heater unit and connect it to main harness.
Make sure lever of mode door motor is fitted into the slit of mode door link.
2. Turn ignition switch to ON.
3. Turn VENT switch ON.
4. Turn DEF switch ON. Check that slide link operates at the full-open position.
Also turn DEF switch ON to check that slide link operates at the fully-open position.

Air Mix Door


TROUBLE DIAGNOSIS PROCEDURE FOR AIR MIX DOOR MOTOR

=NFHA0256

SYMPTOM:

- Air mix door motor does not operate normally.

INSPECTION FLOW




*1: HA-166

*2: HA-165

*3: HA-155

SHA335F

Air Mix Door (Cont'd)




CONTROL SYSTEM INPUT COMPONENT

PBR

NFHA0258

NFHA0258S01

Measure resistance between terminals 1 and 2 at vehicle harness side.







DIAGNOSTIC PROCEDURE

SYMPTOM:


- Air mix door motor does not operate normally.

1	CHECK POWER SUPPLY FOR A/C CONTROL UNIT
Refer to "MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK", HA-158.	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace.

2	CHECK PBR
Refer to HA-164.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace air mix door motor.


3	CHECK FOR OUTPUT OF AUTO AMP.													
Do approx. 10.5 volts exist between air mix door motor harness terminal Nos. 4, 5 and body ground?														
<div><div></div><div>Air mix door motor connector (M50)</div><div></div></div>														
<table><tr><th rowspan="2">Air mix door operation</th><th colspan="2">Terminal No.</th><th rowspan="2">Voltage</th></tr><tr><th>(+)</th><th>(-)</th></tr><tr><td>Cold → Hot</td><td>4</td><td rowspan="2">Body ground</td><td rowspan="2">Approx. 10.5V</td></tr><tr><td>Hot → Cold</td><td>5</td></tr></table>			Air mix door operation	Terminal No.		Voltage	(+)	(-)	Cold → Hot	4	Body ground	Approx. 10.5V	Hot → Cold	5
Air mix door operation	Terminal No.			Voltage										
	(+)	(-)												
Cold → Hot	4	Body ground	Approx. 10.5V											
Hot → Cold	5													
Yes or No														
Yes	▶	GO TO 4.												
No	▶	Replace A/C control unit.												

SHA327F


4	CHECK POWER SUPPLY FOR PBR.
Do approx. 12 volts exist between air mix door motor harness terminal No. 3 and body ground?	
	
Yes or No	
Yes	▶ GO TO 5.
No	▶ Check 10A (No. 19) fuse at fuse block. Refer to EL-10 , "Wiring Diagram — POWER —".

RHA572H


Air Mix Door (Cont'd)

5	CHECK GROUND CIRCUIT FOR PBR.
Check circuit continuity between air mix door motor harness terminal No. 1 and body ground.	
 <p>OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Repair harness or connector.

RHA573H

6	CHECK CIRCUIT CONTINUITY BETWEEN AIR MIX DOOR MOTOR AND A/C CONTROL UNIT
Check circuit continuity between air mix door motor harness terminal Nos. (4), 5 and A/C control unit harness terminal Nos. (22), 23.	
 <p>Continuity should exist. If OK, check harness for short.</p> <p>OK or NG</p>	
OK	▶ Replace air mix door motor.
NG	▶ Repair harness or connector.

RHA380H



CONTROL LINKAGE ADJUSTMENT

Air Mix Door

NFHA0257

NFHA0257S01

1. Install air mix door motor on heater unit and connect it to main harness.
Make sure lever of air mix door is fitted into the slit of the air mix door link.
2. Turn ignition switch to ON.
3. Slide temperature control lever to full cold.
4. Check that air mix door operates properly when temperature control lever is slid to full hot and full cold.

Intake Door

TROUBLE DIAGNOSIS PROCEDURE FOR INTAKE DOOR


=NFHA0135

Symptom:

- Intake door does not change in VENT, B/L or FOOT mode.

Inspection Flow

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Recirculation

- Press recirculation switch.
Recirculation indicator should light.
- Listen for intake door position change (you should hear blower sound change slightly).

NOTE:

Confirm that the RECIRCULATION (REC) switch is canceled in the DEF () and D/F () mode.

If OK (symptom cannot be duplicated), perform complete operational check (*2).
If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check intake door motor circuit. (*1)

OK

INSPECTION END

If the symptom still exist, perform a complete operational check (*2) and check for other symptoms.
[Refer to symptom table, (*3).]
Does another symptom exist?

Yes

Go to Trouble Diagnosis for related symptom.


[Another symptom exists.]

RHA430HA

*1: HA-168

*2: HA-155

*3: HA-154



RHA570H

SYSTEM DESCRIPTION

Intake Door Motor

NFHA0136


NFHA0136S01

The intake door motor is installed on the blower and intake unit. Using a link it opens and closes the intake door.

When RECIRCULATION switch is at REC (except DEF and D/F modes), the A/C control unit sets the intake door at the "RECIRCULATION" position.

RECIRCULATION switch is canceled by MODE switch in DEF and D/F modes.


Intake Door (Cont'd)



DIAGNOSTIC PROCEDURE

SYMPTOM: Intake door motor does not operate normally. NFHA0090**1 CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR**

Does continuity exist between intake door harness terminal No. 5 and body ground?




RHA433H

Yes or No

Yes	▶	GO TO 2.
No	▶	Repair harness or connector.

2 CHECK FOR A/C CONTROL UNIT OUTPUT

Measure voltage across auto amp. harness terminals and body ground.



Recirculation switch condition	Terminals No.		Condition	Voltage V
	(+)	(-)		
REC	20	Body ground	REC	12
	11			0
FRE	11	Body ground	FRE	12
	20			0

0V: Approx. 0V
12V: Approx. 12V


SHA324FA

OK or NG

OK	▶	GO TO 3.
NG	▶	Replace A/C control unit.

3
CHECK CIRCUIT CONTINUITY BETWEEN A/C CONTROL UNIT AND INTAKE DOOR MOTOR

Check circuit continuity between each terminal on A/C control unit and on intake door motor.



Terminal No.		Continuity
A/C CONTROL UNIT	Intake door motor	
11	6	Yes
20	7	
21	4	
24	1	


RHA435HA

Continuity should exist.

If OK, check harness for short.

OK or NG

OK	▶	Replace intake door motor.
NG	▶	Repair harness or connector.



CONTROL LINKAGE ADJUSTMENT

Intake Door Motor

NFHA0093

NFHA0093S04

1. Install intake door motor on blower and intake unit. Ensure that the intake door motor lever is fitted into the slit portion of intake door link.
2. Connect the intake door motor harness connector.
3. Turn ignition switch to ON.
4. Check that intake door operates properly when RECIRCULATION switch is turned ON and OFF.

Blower Motor


TROUBLE DIAGNOSIS PROCEDURE FOR BLOWER MOTOR

=NFHA0138

Symptom:

- Blower motor does not rotate at all.

Inspection Flow




RHA437HA

*1: HA-172

*2: HA-155

*3: HA-154



ELECTRICAL COMPONENTS INSPECTION

=NFHA0139

Fan Switch

NFHA0139S01

Check continuity between terminals at each switch position.


SWITCH POSITION	Continuity between terminals
OFF	No continuity
1	2 — 1 — 6
2	3 — 1 — 6
3	4 — 1 — 6
4	5 — 1 — 6

Blower Motor

NFHA0139S02

Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.



Blower Resistor

NFHA0139S03

Check resistance between terminals.

Terminal No.		Resistance	
(+)	(-)	RHD models	LHD models
3	1	Approx. 1.29 - 1.57Ω	Approx. 0.9 - 1.1Ω
4		Approx. 2.7 - 3.3Ω	Approx. 2.57 - 3.14Ω
2		Approx. 0.45 - 0.56Ω	Approx. 0.36 - 0.44Ω

DIAGNOSTIC PROCEDURE








=NFHA0089

SYMPTOM:

- Blower motor does not rotate.

Test group No.	INCIDENT
1	Fan fails to rotate.
2	Fan does not rotate at 1-speed.
3	Fan does not rotate at 2-speed.
4	Fan does not rotate at 3-speed.
5	Fan does not rotate at 4-speed.

1	DIAGNOSTIC PROCEDURE	
Check if blower motor rotates properly at each fan speed. Conduct checks as per table at above.		
1	▶	GO TO 2.
2, 3, 4	▶	GO TO 8.
5	▶	GO TO 9.

2	CHECK POWER SUPPLY FOR BLOWER MOTOR	
<div>1. Disconnect blower motor harness connector.</div> <div>2. Do approx. 12 volts exist between blower motor harness terminal No. 1 and body ground?</div>		
<div><div><div><div><div></div><div>DISCONNECT</div></div><div></div><div></div></div><div>Blower motor connector (E102)</div></div><div><div><div><div><div></div><div>1</div></div><div>W/L</div><div></div><div></div></div><div></div></div></div></div>		
Yes or No		
Yes	▶	GO TO 3.
No	▶	Check 15A (No. 51 and No. 52) fuses at fuse block. Refer to EL-10 , “Wiring Diagram — POWER —”. Check blower relay.


RHA343FC


3	CHECK CIRCUIT CONTINUITY FOR BLOWER MOTOR	
<div>1. Turn fan control switch to any position except OFF.</div> <div>2. Check circuit continuity between blower motor harness terminal No. 2 and body ground.</div>		
<div></div>		
<div>Continuity should exist.</div> <div>If OK, check harness for short.</div>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Reconnect blower motor harness connector. GO TO 5.

4	CHECK BLOWER MOTOR	
(Refer to Electrical Components Inspection.) (HA-171)		
OK or NG		
OK	▶	INSPECTION END
NG	▶	Replace blower motor.

5	CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND RESISTOR	
Do approx. 12 volts exist between resistor harness terminal No. 1 and body ground?		
<div><p>DISCONNECT</p><p>H.S.</p><p>Resistor connector (M37)</p><p>L/W</p><p>V</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p><p>+</p><p>-</p></div>		

Blower Motor (Cont'd)

6	CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND RESISTOR
Check circuit continuity between blower motor harness terminal No. 2 and resistor harness terminal No. 1.	
 <p>Resistor connector (M37)</p> <p>Blower motor connector (E102)</p> <p>L/W</p> <p>L/W</p> <p>Continuity should exist. If OK, check harness for short.</p>	
RHA576FB	
OK or NG	
NG	▶ Repair harness or connector.

7	CHECK GROUND CIRCUIT FOR FAN SWITCH
Check circuit continuity between fan switch harness terminal No. 1 and body ground.	
 <p>Fan switch connector (M58)</p> <p>B</p>	
RHA440H	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair harness or connector.

8	CHECK RESISTOR AFTER DISCONNECTING IT
(Refer to Electrical Components Inspection.) (HA-171)	
OK or NG	
OK	▶ Reconnect resistor harness connector. GO TO 9.
NG	▶ Replace resistor.

9	CHECK FAN SWITCH CIRCUIT																	
Do approx. 12 volts exist between each fan switch harness terminal and body ground?																		
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> </div> <div style="flex: 1; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2">Test group No.</th> <th colspan="2">Terminals No.</th> <th rowspan="2">Voltage</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>5</td> <td rowspan="4">Body ground</td> <td rowspan="4">Approx. 12V</td> </tr> <tr> <td>3</td> <td>4</td> </tr> <tr> <td>4</td> <td>3</td> </tr> <tr> <td>5</td> <td>2</td> </tr> </tbody> </table> </div> </div>			Test group No.	Terminals No.		Voltage	(+)	(-)	2	5	Body ground	Approx. 12V	3	4	4	3	5	2
Test group No.	Terminals No.			Voltage														
	(+)	(-)																
2	5	Body ground	Approx. 12V															
3	4																	
4	3																	
5	2																	
SHA325F																		
Yes or No																		
Yes	▶	GO TO 11.																
No	▶	GO TO 10.																

10	CHECK CIRCUIT CONTINUITY BETWEEN FAN SWITCH AND RESISTOR															
Check circuit continuity between fan switch harness terminal and resistor harness terminal.																
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> </div> <div style="flex: 1; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">Terminal No.</th> <th rowspan="2">Continuity</th> </tr> <tr> <th>Fan switch</th> <th>Resistor</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>4</td> <td rowspan="4">Yes</td> </tr> <tr> <td>3</td> <td>3</td> </tr> <tr> <td>4</td> <td>2</td> </tr> <tr> <td>5</td> <td>1</td> </tr> </tbody> </table> </div> </div>			Terminal No.		Continuity	Fan switch	Resistor	2	4	Yes	3	3	4	2	5	1
Terminal No.		Continuity														
Fan switch	Resistor															
2	4	Yes														
3	3															
4	2															
5	1															
SHA326F																
<p>Continuity should exist.</p> <p>If OK, check harness for short.</p>																
OK or NG																
NG	▶	Repair harness or connector.														

11	CHECK FAN SWITCH AFTER DISCONNECTING IT	
(Refer to Electrical Components Inspection.) (HA-171)		
OK or NG		
OK	▶	INSPECTION END
NG	▶	Replace fan switch.

Magnet Clutch


TROUBLE DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH

=NFHA0119

Symptom:

- Magnet clutch does not operate when A/C switch and fan switch are ON.

Inspection Flow



RHA446HA

*1: HA-206

*3: HA-155

*5: **MA-15**

*2: HA-177

*4: HA-154

DIAGNOSTIC PROCEDURE

SYMPTOM:


- Magnet clutch does not engage when A/C switch and fan switch are ON.

1	CHECK POWER SUPPLY FOR COMPRESSOR
<p>Disconnect compressor harness connector.</p> <p>Do approx. 12 volts exist between compressor harness terminal No. 1 and body ground?</p> <div data-bbox="646 470 1013 784"> <p>Compressor connector (A3)</p> <p>B/P</p> <p>V</p> <p>A/C</p> </div> <p style="text-align: right;">RHA747FH</p> <p style="text-align: center;">Yes or No</p>	
Yes	▶ GO TO 2.
No	▶ Disconnect A/C relay. GO TO 3.


2	CHECK MAGNET CLUTCH COIL
<p style="text-align: center;">OK or NG</p> <p>NG ▶ Replace magnet clutch. Refer to HA-198.</p>	

3	CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND COMPRESSOR
<p>Check circuit continuity between A/C relay harness terminal No. 3 and compressor harness terminal No. 1.</p> <div data-bbox="678 1243 1013 1568"> <p>Compressor connector (A3)</p> <p>A/C relay connector (E71)</p> <p>Y/B</p> <p>Ω</p> </div> <p style="text-align: right;">RHA447H</p> <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair harness or connector.

Magnet Clutch (Cont'd)

4	CHECK POWER SUPPLY FOR A/C RELAY
Disconnect A/C relay. Do approx. 12 volts exist between A/C relay harness terminal Nos. 1, 5 and body ground?	
	
RHA439HA	
Yes or No	
Yes	▶▶ GO TO 5.
No	▶▶ Check power supply circuit and 10A (No. 19, 66) fuse at fuse block. Refer to EL-10 , "Wiring Diagram — POWER —".


5	CHECK A/C RELAY AFTER DISCONNECTING IT
Refer to HA-182.	
OK or NG	
OK	▶▶ Reconnect A/C relay. GO TO 6.
NG	▶▶ Replace A/C relay.


6	CHECK COIL SIDE CIRCUIT OF A/C RELAY
Do approx. 12 volts exist between ECM harness terminal No. 27 and body ground?	
	
SHA311FA	
Yes or No	
Yes	▶▶ GO TO 8.
No	▶▶ Disconnect A/C relay. Disconnect ECM harness connector. GO TO 7.


7	CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND ECM
<p>Check circuit continuity between A/C relay harness terminal No. 2 and ECM harness terminal No. 27.</p> <div style="text-align: center;"> </div> <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: right;">RHA448H</p>	
OK or NG	
NG	▶ Repair harness or connector.

8	CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL
<p>Do approx. 0 volts between ECM harness terminal No. 51 and body ground?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">RHA575H</p>	
Yes or No	
Yes	▶ GO TO 10.
No	▶ Check ECM. Refer to EC-119 , "ECM Terminals and Reference Value". Repair harness or connector.

9	CHECK REFRIGERANT PRESSURE SENSOR
<p>Refer to HA-182.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Disconnect A/C switch harness connector. GO TO 10.
NG	▶ Replace refrigerant pressure sensor.


10 CHECK VOLTAGE FOR ECM		
Do approx. 12 volts exist between ECM harness terminal No. 45 and body ground?		
		
SHA312F		
Yes or No		
Yes	▶	GO TO 11.
No	▶	Check ECM. Refer to EC-119 , "ECM Terminals and Reference Value". Repair harness or connector.

11 CHECK CIRCUIT CONTINUITY BETWEEN A/C CONTROL UNIT AND FAN SWITCH		
Check circuit continuity between A/C control unit harness terminal No. 12 and fan switch harness terminal No. 6.		
		
RHA450H		
<p>Continuity should exist.</p> <p>If OK, check harness for short.</p>		
OK or NG		
OK	▶	GO TO 12.
NG	▶	Repair harness or connector.

12	CHECK BODY GROUND CIRCUIT FOR FAN SWITCH
Does continuity exist between fan switch harness terminal No. 1 and body ground?	
<div></div>	
RHA451H	
Yes or No	
Yes	▶ GO TO 13.
No	▶ Repair harness or connector.

13	CHECK FAN SWITCH
Refer to HA-171.	
OK or NG	
OK	▶ Replace A/C control unit.
NG	▶ Replace fan switch.

Magnet Clutch (Cont'd)



ELECTRICAL COMPONENTS INSPECTION

=NFHA0092

A/C Relay

NFHA0092S07

Check continuity between terminal Nos. 3 and 5.

Conditions	Continuity
12V direct current supply between terminal Nos. 1 and 2	Yes
No current supply	No



If NG, replace relay.

Refrigerant Pressure Sensor

NFHA0092S08

Make sure that higher A/C refrigerant pressure results in higher refrigerant-pressure sensor output voltage.

	OFF kPa (bar, kg/cm ² , psi)
Low-pressure side	Decreasing to 0.18 (0.0018, 0.00184, 0.03)
High-pressure side	Increasing to 2.74 (0.0274, 0.0279, 0.40)



Insufficient Cooling


TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING

=NFHA0150

Symptom:

- Insufficient Cooling.

Inspection Flow



SHA418FA


*1: HA-163
*2: HA-186
*3: HA-184

*4: HA-155
*5: HA-154
*6: HA-198

*7: HA-163
*8: **MA-15**
*9: **EC-366**

PERFORMANCE TEST DIAGNOSES

NFHA0082




SHA419F

*1: HA-186

*3: HA-187

*4: HA-163

*2: HA-186



SHA334F

*7: HA-200

*8: HA-170

*9: **MA-15**

Insufficient Cooling (Cont'd)


PERFORMANCE TEST

=NFHA0083

Test Condition

NFHA0083S01

Testing must be performed as follows:

Vehicle location	Indoors or in the shade (in a well-ventilated place)
Doors	Closed
Door windows	Open
Hood	Open
TEMP.	Max. COLD
Discharge Air	Face Vent
REC switch	 (Recirculation) set
FAN speed	High speed
Engine speed	Idle speed

Operate the air conditioning system for 10 minutes before taking measurements.

Test Reading

NFHA0083S02

Recirculating-to-discharge Air Temperature Table

NFHA0083S0201

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	15 (59)	3.5 - 5.4 (38 - 42)
	20 (68)	6.6 - 8.9 (44 - 48)
	25 (77)	9.5 - 12.6 (49 - 55)
	30 (86)	13.4 - 16.5 (56 - 62)
	35 (95)	17.6 - 21.3 (64 - 70)
60 - 70	15 (59)	5.4 - 7.1 (42 - 45)
	20 (68)	8.9 - 11.0 (48 - 52)
	25 (77)	12.6 - 15.4 (55 - 60)
	30 (86)	16.5 - 20.0 (62 - 68)
	35 (95)	21.3 - 24.8 (70 - 77)

Ambient Air Temperature-to-operating Pressure Table

NFHA0083S0202

Ambient air		High-pressure (Discharge side) kPa (bar, kg/cm ² , psi)	Low-pressure (Suction side) kPa (bar, kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	15 (59)	539 - 657 (5.39 - 6.57, 5.5 - 6.7, 78 - 95)	177 - 216 (1.77 - 2.16, 1.8 - 2.2, 26 - 31)
	20 (68)	677 - 824 (6.77 - 8.24, 6.9 - 8.4, 98 - 119)	167 - 206 (1.67 - 2.06, 1.7 - 2.1, 24 - 30)
	25 (77)	843 - 1,030 (8.43 - 10.30, 8.6 - 10.5, 122 - 149)	177 - 226 (1.77 - 2.26, 1.8 - 2.3, 26 - 33)
	30 (86)	1,030 - 1,275 (10.30 - 12.75, 10.5 - 13.0, 149 - 185)	216 - 255 (2.16 - 2.55, 2.2 - 2.6, 31 - 37)
	35 (95)	1,245 - 1,520 (12.45 - 15.20, 12.7 - 15.5, 181 - 220)	265 - 324 (2.65 - 3.24, 2.7 - 3.3, 38 - 47)


TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE

NFHA0084

Whenever system's high and/or low side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (normal) pressure range. Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-186 ("Ambient air temperature-to-operating pressure table").


Both High and Low-pressure Sides are Too High.

NFHA0084S01

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
Both high and low-pressure sides are too high. A  AC359A	<ul style="list-style-type: none"> Pressure is reduced soon after water is splashed on condenser. 	Excessive refrigerant charge in refrigeration cycle	Reduce refrigerant until specified pressure is obtained.
	Air suction by cooling fan is insufficient.	Insufficient condenser cooling performance ↓ 1. Condenser fins are clogged. 2. Improper fan rotation of cooling fan	<ul style="list-style-type: none"> Clean condenser. Check and repair cooling fan as necessary.
	<ul style="list-style-type: none"> Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (1.96 bar, 2 kg/cm², 28 psi). It then decreases gradually thereafter. 	Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.) ↓ Air in refrigeration cycle	Evacuate repeatedly and recharge system.
	Engine tends to overheat.	Engine cooling systems malfunction.	Check and repair each engine cooling system.
	<ul style="list-style-type: none"> An area of the low-pressure pipe is colder than areas near the evaporator outlet. Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> Excessive liquid refrigerant on low-pressure side Excessive refrigerant discharge flow Expansion valve is open a little compared with the specification. ↓ 1. Improper thermal valve installation 2. Improper expansion valve adjustment	Replace expansion valve.


High-pressure Side is Too High and Low-pressure Side is Too Low.

NFHA0084S02

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p style="text-align: right;">AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> ● Check and repair or replace malfunctioning parts. ● Check lubricant for contamination.


High-pressure Side is Too Low and Low-pressure Side is Too High.

NFHA0084S03

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p style="text-align: right;">AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>
	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings.</p>	<p>Replace compressor.</p>


Both High- and Low-pressure Sides are Too Low.

NFHA0084S04

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p>AC353A</p>	<ul style="list-style-type: none"> There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. Liquid tank inlet and expansion valve are frosted. 	Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)	<ul style="list-style-type: none"> Replace liquid tank. Check lubricant for contamination.
	<ul style="list-style-type: none"> Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. Expansion valve inlet may be frosted. Temperature difference occurs somewhere in high- pressure side 	High-pressure pipe located between receiver drier and expansion valve is clogged.	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	<ul style="list-style-type: none"> Expansion valve and liquid tank are warm or only cool when touched. 	Low refrigerant charge ↓ Leaking fittings or components	Check refrigerant for leaks. Refer to "Checking Refrigerant Leaks", HA-206.
	There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.	Expansion valve closes a little compared with the specification. ↓ 1. Improper expansion valve adjustment 2. Malfunctioning thermal valve 3. Outlet and inlet may be clogged.	<ul style="list-style-type: none"> Remove foreign particles by using compressed air. Check lubricant for contamination.
	An area of the low-pressure pipe is colder than areas near the evaporator outlet.	Low-pressure pipe is clogged or crushed.	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	Air flow volume is not enough or is too low.	Evaporator is frozen. ↓ Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)	Replace compressor.


Low-pressure Side Sometimes Becomes Negative.

NFHA0084S05

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p style="text-align: right;">AC354A</p>	<ul style="list-style-type: none"> Air conditioning system does not function and does not cyclically cool the compartment air. The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> Drain water from refrigerant or replace refrigerant. Replace liquid tank.

Low-pressure Side Becomes Negative.

NFHA0084S06

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p>F</p>  <p style="text-align: right;">AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. If due to foreign particles, remove expansion valve and remove particles with dry and compressed air (not shop air). If either of the above methods cannot correct the problem, replace expansion valve. Replace liquid tank. Check lubricant for contamination.

Insufficient Heating


TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT HEATING

=NFHA0140

Symptom:

- **Insufficient Heating.**

Inspection Flow



RHA444HA

*1: HA-163

*4: **MA-16**

*6: **LC-16**

*2: HA-155

*5: **LC-11**

*7: **MA-16**

*3: HA-154

Noise


TROUBLE DIAGNOSIS PROCEDURE FOR NOISE

=NFHA0080

Symptom:

- Noise

Inspection Flow



SHA336F

*1: HA-200

*3: HA-195

*4: MA-15

*2: HA-200

HFC-134a (R-134a) Service Procedure

NFHA0094

NFHA0094S01

NFHA0094S0101


SETTING OF SERVICE TOOLS AND EQUIPMENT

Discharging Refrigerant

WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Use only approved recovery/recycling equipment to discharge HFC-134a (R-134a) refrigerant. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.

Example




SHA539DE

Evacuating System and Charging Refrigerant


NFHA0094S0102

Example


Preferred (Best) method



Alternate method



Recovered lubricant. Refer to
"CHECKING AND ADJUSTING",
*1.



SHA386F

*1: HA-195

*3: HA-207

*4: HA-184

*2: HA-206

Maintenance of Lubricant Quantity in Compressor

The lubricant in the compressor circulates through the system with the refrigerant. Add lubricant to compressor when replacing any component or after a large gas leakage occurred. It is important to maintain the specified amount. If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)

LUBRICANT

Name: Nissan A/C System Oil Type S

Part number: KLH00-PAGS0


NFHA0095S01

CHECKING AND ADJUSTING

Adjust the lubricant quantity according to the test group shown below.

NFHA0095S02

1	LUBRICANT RETURN OPERATION	
Can lubricant return operation be performed?		
<ul style="list-style-type: none">● A/C system works properly.● There is no evidence of a large amount of lubricant leakage.		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	PERFORM LUBRICANT RETURN OPERATION, PROCEEDING AS FOLLOWS	
<div>1. Start engine, and set the following conditions: Test condition Engine speed: Idling to 1,200 rpm A/C or AUTO switch: ON Blower speed: Max. position Temp. control: Optional [Set so that intake air temperature is 25 to 30°C (77 to 86°F).]</div> <div>2. Next item is for V-6 compressor. Connect the manifold gauge, and check that the high pressure side pressure is 588 kPa (5.9 bar, 6 kg/cm², 85 psi) or higher. If less than the reference level, attach a cover to the front face of the condenser to raise the pressure.</div> <div>3. Perform lubricant return operation for about 10 minutes.</div> <div>4. Stop engine.</div> <div>CAUTION: If excessive lubricant leakage is noted, do not perform the lubricant return operation.</div>		
		GO TO 3.

3	CHECK COMPRESSOR	
Should the compressor be replaced?		
Yes or No		
Yes	▶	GO TO HA-196.
No	▶	GO TO 4.

4	CHECK ANY PART	
Is there any part to be replaced? (Evaporator, condenser, liquid tank or in case there is evidence of a large amount of lubricant leakage.)		
Yes or No		
Yes	▶	GO TO HA-196.
No	▶	Carry out the A/C performance test.

Lubricant Adjusting Procedure for Components Replacement Except Compressor

NFHA0095S0201

After replacing any of the following major components, add the correct amount of lubricant to the system.

Amount of lubricant to be added

Part replaced	Lubricant to be added to system	Remarks
	Amount of lubricant mℓ (Imp fl oz)	
Evaporator	75 (2.6)	—
Condenser	75 (2.6)	—
Liquid tank	5 (0.2)	Add if compressor is not replaced. *1
In case of refrigerant leak	30 (1.1)	Large leak
	—	Small leak *2

*1: If compressor is replaced, addition of lubricant is included in the table.

*2: If refrigerant leak is small, no addition of lubricant is needed.

Lubricant Adjustment Procedure for Compressor Replacement


NFHA0095S0202

- Discharge refrigerant into the refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
- Remove the drain plug of the “old” (removed) compressor. Drain the lubricant into a graduated container and record the amount of drained lubricant.
- Remove the drain plug and drain the lubricant from the “new” compressor into a separate, clean container.
- Measure an amount of new lubricant installed equal to amount drained from “old” compressor. Add this lubricant to “new” compressor through the suction port opening.
- Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to “new” compressor through the suction port opening.
- Torque the drain plug.

V-6 compressor:

18 - 19 N·m (1.8 - 1.9 kg-m, 13 - 14 ft-lb)

- If the liquid tank also needs to be replaced, add an additional 5 mℓ (0.2 Imp fl oz) of lubricant at this time.
Do not add this 5 mℓ (0.2 Imp fl oz) of lubricant if only replacing the compressor.




RHA065DI

**Compressor
REMOVAL AND INSTALLATION**

NFHA0096

SEC. 274-275




RHA463E


**Compressor Clutch
OVERHAUL**

NFHA0097

SEC. 274




RHA122F




REMOVAL


- When removing center bolt, hold clutch disc with clutch disc wrench. NFHA0098




- Remove the clutch disc using the clutch disc puller. Insert the holder's three pins into the holes in the clutch disc. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the clutch disc. After removing the clutch disc, remove the shims from either the drive shaft or the clutch disc.




- Remove the snap ring using external snap ring pliers.




- Pulley removal**
Position the center pulley puller on the end of the drive shaft, and remove the pulley assembly using any commercially available pulley puller.
To prevent the pulley groove from being deformed, the puller claws should be positioned onto the edge of the pulley assembly.




Compressor Clutch (Cont'd)



- Remove the field coil harness clip using a pair of pliers.



- Remove the snap ring using external snap ring pliers.



INSPECTION

Clutch Disc

NFHA0099

If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

NFHA0099S01

Pulley


NFHA0099S02

Check the appearance of the pulley assembly. If the contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

NFHA0099S03


Check coil for loose connection or cracked insulation.




INSTALLATION

NFHA0100


- Install the field coil.
Be sure to align the coil's pin with the hole in the compressor's front head.
- Install the field coil harness clip using a screwdriver.




- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



- Install the clutch disc on the drive shaft, together with the original shim(s). Press the clutch disc down by hand.



- Using the holder to prevent clutch disc rotation, tighten the bolt to 14 N·m (1.4 kg-m, 10 ft-lb) torque.
After tightening the bolt, check that the pulley rotates smoothly.



- Check clearance around the entire periphery of clutch disc.
Disc-to-pulley clearance:
0.3 - 0.6 mm (0.012 - 0.024 in)
If the specified clearance is not obtained, replace adjusting spacer and readjust.

Break-in Operation


NFHA0100S01

When replacing compressor clutch assembly, always carry out the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.

Heater Unit (Heater Core) REMOVAL

NFHA0261

This illustration is for LHD models.
The layout for RHD models is symmetrically opposite.



RHA567H

1. Drain the cooling system. Refer to **MA-16**, "Changing Engine Coolant".
2. Discharge the A/C system. Refer to HA-108.
3. Disconnect the two heater hoses from inside the engine compartment.
4. Remove the blower and cooling unit. Refer to HA-203.
5. Remove the steering member assembly. Refer to **BT-20**, "Removal and Installation - Instrument Panel Assembly".
6. Remove the heater unit.
7. Remove the heater core.

INSTALLATION

NFHA0262



Installation is basically the reverse order of removal.

When filling radiator with coolant, refer to MA-16, "Changing Engine Coolant".

Recharge the A/C system. Refer to HA-108.

Blower and Cooling Unit (A/C Evaporator) REMOVAL

NFHA0263



1. Discharge the A/C system. Refer to HA-193.
2. Disconnect the two refrigerant lines from the engine compartment.
Cap the A/C lines to prevent moisture from entering the system.
3. Remove the glove box and mating trim. Refer to **BT-20**, "Removal and Installation - Instrument Panel Assembly".
4. Disconnect the thermal amp. connector.
5. Disconnect the fan resistor and blower motor connector.
6. Remove the blower and cooling unit.
7. Separate the blower and cooling unit case, and remove the evaporator.

INSTALLATION

Installation is basically the reverse order of removal.
Recharge the A/C system. Refer to HA-193.

NFHA0264


Refrigerant Lines

REMOVAL AND INSTALLATION

=NFHA0101

- Refer to page HA-127 regarding "Precautions for Refrigerant Connection".


LHD models



- : Refrigerant leak checking points
- : (Tightening torque)
- □ : (Wrench size)
- : (O-ring size)
- ⊗ : N·m (kg-m, in-lb)
- ⊕ : N·m (kg-m, ft-lb)
- A : 2.9 - 5.9 (0.29 - 0.61, 26 - 52)
- B : 7.8 - 19.6 (0.78 - 2.00, 68 - 173)
- C : 15 - 24 (1.5 - 2.4, 11 - 18)

RHA423HB

RHD models



- : Refrigerant leak checking points
- : (Tightening torque)
- □ : (Wrench size)
- : (O-ring size)
- ⊗ : N•m (kg-m, in-lb)
- A** : 2.9 - 5.9 (0.29 - 0.61, 26 - 52)
- B** : 7.8 - 19.6 (0.78 - 2.00, 68 - 173)
- ⊕ : N•m (kg-m, ft-lb)
- C** : 15 - 24 (1.5 - 2.4, 11 - 18)

RHA900H

- Refer to HA-127, "Precautions for Refrigerant Connection".


CHECKING REFRIGERANT LEAKS

=NFHA0102

Preliminary Check

NFHA0102S01

Perform a visual inspection of all refrigeration parts, fittings, hoses, and components for signs of A/C lubricant leakage, damage and corrosion. Take note of the areas with A/C lubricant leakage to allow extra time in these areas with electronic leak detector.




Precautions for Handling Leak Detector

NFHA0102S02


When performing a refrigerant leak check, use an A/C leak detector or equivalent. Ensure that the instrument is calibrated and set properly per the operating instructions.

The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.


Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and lubricants, may falsely trigger the leak detector. Make sure the surfaces to be checked are clean. Clean with a dry cloth or blow off with shop air. Do not allow the sensor tip of the detector to contact with any substance. This can also cause false readings and may damage the detector.



1. Position probe approximately 5 mm (3/16 in) away from point to be checked.



2. When testing, circle each fitting completely with probe.



3. Move probe along component approximately 25 to 50 mm (1 to 2 in)/sec.

Checking Procedure

NFHA0102S03

To prevent inaccurate or false readings, make sure there is no refrigerant vapor, shop chemicals, or cigarette smoke in the vicinity of the vehicle. Perform the leak test in calm area (low air/wind movement) so that the leaking refrigerant is not dispersed.

1. Turn engine off.
2. Connect a suitable A/C manifold gauge set to the A/C service ports.
3. Check if the A/C refrigerant pressure is at least 345 kPa (3.45 bar, 3.52 kg/cm², 50 psi) above 16°C (61°F). If less than specification, recover/evacuate and recharge the system with the specified amount of refrigerant.

NOTE:

At temperatures below 16°C (61°F), leaks may not be detected since the system may not reach 345 kPa (3.45 bar, 3.52 kg/cm², 50 psi).

4. Conduct the leak test from the high side (compressor discharge **a** to evaporator inlet **e**) to the low side (evaporator discharge **e** to shaft seal **j**). Refer to HA-204. Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detector probe completely around the connection/component.


- **Compressor**
Check the fitting of high and low pressure hoses, relief valve and shaft seal.
- **Liquid tank**
Check the refrigerant pressure sensor, tube fitting, weld seams and the fusible plug mount.
- **Service valves**
Check all around the service valves. Ensure service valve caps are secured on the service valves (to prevent leaks).

NOTE:

After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any false readings by leak detector.

- **Cooling unit (Evaporator)**
With engine OFF, turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Wait a minimum of 10 minutes accumulation time (refer to the manufacturer's recommended procedure for actual wait time) before inserting the leak detector probe into the drain hose. Keep the probe inserted for at least ten seconds. Use caution not to contaminate the probe tip with water or dirt that may be in the drain hose.

5. If a leak detector detects a leak, verify at least once by blowing compressed air into area of suspected leak, then repeat check as outlined above.
6. Do not stop when one leak is found. Continue to check for additional leaks at all system components. If no leaks are found, perform steps 7 - 10.
7. Start engine.
8. Set the heater A/C control as follows:
 - 1) A/C switch ON.
 - 2) Face mode
 - 3) Recirculation switch ON
 - 4) Max cold temperature
 - 5) Fan speed high
9. Run engine at 1,500 rpm for at least 2 minutes.
10. Turn engine off and perform leak check again following steps 4 through 6 above.



Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector at the compressor. The pressure on the high pressure side will gradually drop after refrigerant circulation stops and pressure on the low pressure side will gradually rise, as shown in the graph. Some leaks are more easily detected when pressure is high.

11. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component as necessary.
12. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
13. Conduct A/C performance test to ensure system works properly.

Belt

TENSION ADJUSTMENT

- Refer to *MA-15*, "Checking Drive Belt".


NFHA0103

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve

INSPECTION

- Refer to EC-510, “Description” and HA-141.

NFHA0104



Ventilation Air Filter


FUNCTION

Air inside passenger compartment is kept clean at either recirculation or fresh mode by installing ventilation air filter into cooling unit. NFHA0268

NOTE:

To replace ventilation air filter, refer to “PERIODIC MAINTENANCE”, MA-7.

Caution label is fixed inside the glove box.



REPLACEMENT PROCEDURE

NFHA0269

1. Remove glove box.
2. Remove instrument lower panel from instrument panel.
3. Remove filter cover fixed clip.
4. Slide the filter cover to the upper side and then remove it.
5. Take out the lower side ventilation air filter from cooling unit.
6. Then slide upper side filter to the bottom position and take off the ventilation air filter from the cooling unit.
7. Replace with new one and reinstall on cooling unit.
8. Reinstall filter cover, clip, instrument lower panel and glove box.

Manual

COMPRESSOR

NFHA0105

Model		CALSONIC make V-6
Type		V-6 variable displacement
Displacement cm ³ (cu in)/rev.	Max.	184 (11.228)
	Min.	14.5 (0.885)
Cylinder bore x stroke mm (in)		37 (1.46) x [2.3 - 28.6 (0.091 - 1.126)]
Direction of rotation		Clockwise (viewed from drive end)
Drive belt		Poly V

LUBRICANT

NFHA0106

Model		CALSONIC make V-6
Name		Nissan A/C System Oil Type S
Part number*		KLH00-PAGS0
Capacity mℓ (Imp fl oz)	Total in system	200 (7.0)
	Compressor (Service part) charging amount	200 (7.0)

*: Always check with Parts Department for the latest parts information.

REFRIGERANT

NFHA0107

Type	HFC-134a (R-134a)
Capacity kg (lb)	0.60 - 0.70 (1.32 - 1.54)

ENGINE IDLING SPEED (WHEN A/C IS ON)

NFHA0108

- Refer to **EC-510**, "Description".

BELT TENSION

NFHA0109

- Refer to **MA-15**, "Checking Drive Belt".